

# **CARBON BLACK**

5100

MW: 12.01 CAS: 1333-86-4 RTECS: FF5800000

carbons (PAHs)

METHOD: 5100, Issue 1 EVALUATION: FULL Issue 1: 30 April 2015

**OSHA:** 3.5 mg/m³[1] **PROPERTIES:** Solid; may contain polynuclear aromatic hydro-

NIOSH: 3.5 mg/m³ (in presence of PAHs: carcinogen/PAHs to

± 15.5%

0.1 mg/m³, cyclohexane extractable fraction) [2]

For other OELs

**ACCURACY:** 

and guidelines: See references [3,4]

SYNONYMS: Acetylene black; amorphous carbon; furnace black; lamp black

#### **SAMPLING MEASUREMENT** SAMPLER: INTERNAL CAPSULE, (tared 37-mm, 2- to 5-µm **TECHNIQUE:** GRAVIMETRIC (INTERNAL CAPSULE WEIGHT) PVC filter melded to PVC housing) in 37-mm **ANALYTE:** Carbon black 2-piece cassette FLOW RATE: 1 to 2 L/min **BALANCE:** 0.001 mg sensitivity; use same balance before and after sample collection VOL-MIN: 75 L @ 3.5 mg/m<sup>3</sup> 1400 L @ 3.5 mg/m<sup>3</sup> **CALIBRATION:** National Institute of Standards and -MAX: Technology (NIST), Class S-1.1 weights or **SHIPMENT:** Routine **ASTM Class 1 weights SAMPLE RANGE:** 0.25 to 5 mg per sample STABILITY: 28 days minimum **ESTIMATED BLANKS:** Minimum of 2 field blanks per batch LOD: 0.075 mg per sample **PRECISION** ( $\overline{S}_r$ ): 0.031 at 2 mg per sample [5] **ACCURACY RANGE STUDIED:** 0.1 to 4 mg/sample **BIAS:** 0.058 [5] **OVERALL** PRECISION $(\hat{S}_{rt})$ : 0.059 [5]

**APPLICABILITY:** The working range is 1.5 to 25 mg/m³ for a 200-L air sample. This method is not applicable for the determination of "cyclohexane-solubles" [3]. The method is nonspecific; information on any other particulate materials that may be present should be assessed.

**INTERFERENCES:** Moisture and static electricity can affect gravimetric measurements. Humidity control and minimization of static effects are addressed in this procedure. The presence of co-sampled airborne particulate material is a positive interference since this is a gravimetric method.

**OTHER METHODS:** This method is preferred over Method 5000, Issue 2 [6], and is similar to Method 0501 for particulates not otherwise regulated [8]. OSHA method PV2121 describes a similar procedure (but for respirable sampling) using an alternative sampler design [9].

#### **EQUIPMENT:**

- 1. Sampler: Internal capsule, 37-mm PVC, 2- to 5-μm pore size membrane or equivalent hydrophobic filter attached to PVC housing and supporting pad in 37-mm 2-piece cassette filter holder NOTE: The cassettes should be fabricated so as to ensure complete sealing of the internal capsule after sample collection.
- 2. Personal sampling pump, 1 to 2 L/min, with flexible connecting tubing
- 3. Microbalance capable of weighing to ±0.001 mg
- 4. Static neutralizer; e.g. <sup>210</sup>Po; replace no more than nine months after production date
- 5. Tool for handling internal capsules, e.g., forceps (preferably plastic)
- 6. Environmental chamber or room for balance (e.g.  $20 \pm 1$  °C and  $50 \pm 5\%$  RH)

**SPECIAL PRECAUTIONS:** Carbon black containing polynuclear aromatic hydrocarbons (cyclohexane - extractable materials) in excess of 0.1% (w/w) should be treated as a suspect carcinogen [3].

#### PREPARATION OF FILTER CAPSULES BEFORE SAMPLING:

- 1. Equilibrate the PVC filter capsules in an environmentally controlled weighing area or chamber for at least 24 h.
  - NOTE: An environmentally controlled chamber is desirable, but not required.
- 2. Place backup pads in filter cassette bottom sections.
- 3. Weigh the filter capsules in an environmentally controlled area or chamber. Record the capsule tare weight, W<sub>1</sub> (mg).
  - a. Zero the balance before each weighing.
  - b. Handle the filter capsule with forceps. Pass the capsule over an antistatic radiation source. Repeat this step if the capsule does not release easily from the forceps or if it attracts balance pan. Static electricity can cause erroneous weight readings.
- 4. Assemble the filter capsules in the filter cassettes and close firmly so that leakage around the internal capsule will not occur. Place a plug in each opening of the filter cassette. Place a cellulose shrink band around the filter cassette, allow to dry, and label the cassette with indelible ink.

### **SAMPLING:**

- 5. Calibrate each personal sampling pump with a representative sampler in line.
- 6. Sample at 1 to 2 L/min for a total sample volume of 75 to 1400 L. Do not exceed a filter capsule loading of approximately 5 mg total dust. Take two to four replicate samples for each batch of field samples for quality assurance on the sampling procedure.

#### **SAMPLE PREPARATION:**

- 7. Wipe dust from the external surface of the filter cassette with a moist paper towelette to minimize contamination. Discard the towelette.
- 8. Remove the top and bottom plugs from the filter cassette. Equilibrate for at least 24 h in the balance room.
- 9. Using forceps, open the cassette and remove the internal capsule gently to avoid loss of dust or damage to the capsule.

#### **CALIBRATION AND QUALITY CONTROL:**

- 10. Zero the microbalance before all weighings. Use the same microbalance for weighing filter capsules before and after sample collection. Calibrate the balance with National Institute of Standards and Technology Class S-1.1 or ASTM Class 1 weights.
- 11. Process laboratory blanks, spiked QC samples and field blanks at a minimum frequency of 1 per 20 field samples. Internal capsules used for QC samples should come from the same lot. Spiked QC samples, loaded with 0.25 to 4 mg of material per internal capsule, should be prepared using weight-stable material such as Arizona Road Dust [10].

#### **MEASUREMENT:**

12. Weigh each capsule, including field blanks. Record the post-sampling weight, W<sub>2</sub> (mg). Record anything remarkable about a capsule (e.g., overloading, leakage, wet, torn, etc.).

#### **CALCULATIONS:**

13. Calculate the concentration, C (mg/m³), of carbon black in the air volume sampled, V (L):

$$C = \frac{(W_2 - W_1) - (B_2 - B_1)}{V} 10^3 \text{ , mg/m}^3$$

where:  $W_1$  = tare weight of capsule before sampling (mg)

 $W_2$  = post-sampling weight of sample-containing capsule (mg)  $B_1$  = mean tare weight of blank capsules (mg)

B, = mean post-sampling weight of blank capsules (mg)

# **EVALUATION OF METHOD:**

Lab testing was carried out using blank internal capsules and with capsules spiked with 0.1 – 4 mg of NIST SRM 1648 (Urban Particulate Matter) and Arizona Road Dust (Air Cleaner Test Dust) [5]. Precision and accuracy data are given on page 5100-1. Weight stability over 28 days was verified for both blanks and spiked capsules [5]. Independent laboratory testing on blanks and field samples have verified long-term weight stability as well as sampling and analysis uncertainty estimates [5].

#### **REFERENCES:**

- [1] CFR. 29 CFR Part 1910.1000. Code of Federal Regulations. Washington, DC: U.S. Government Printing Office, Office of the Federal Register.
- [2] NIOSH [2005]. NIOSH pocket guide to chemical hazards. Barsan ME, ed. Cincinnati OH: U.S. Department of Health and Human Services, Centers for Disease Control and Prevention, National Institute for Occupational Safety and Health. DHHS (NIOSH) Publication no. 2005-149.
- [3] ACGIH [2013]. TLVs and BEIs based on the documentation of the Threshold Limit Values for chemical substances and physical agents and Biological Exposure Indices. Cincinnati, Ohio: American Conference of Governmental Industrial Hygienists. [www.acgih.org]. [Date accessed: February, 2015.]
- [4] Institut fur Arbeitsschutz der Deutschen Gesetzlichen Unfallversicherung [2014]. GESTIS-Database on hazardous substances. (German Social Accident Insurance). Sankt Augustin, Germany: IFA. http://www.dquv.de/ifa/Gefahrstoffdatenbanken/GESTIS-Stoffdatenbank/index-2. jsp [Date accessed: February, 2015.]

- [5] NIOSH [2014]. Backup Data Report-NIOSH 0501 and 5100. By O'Connor SP, O'Connor PF, Feng HA, Ashley K. Cincinnati, OH: U.S. Department of Health and Human Services, Centers for Disease Control and Prevention, National Institute for Occupational Safety and Health. [http://www.cdc.gov/niosh/docs/2003-154/pdfs/bud/1453\_bud.pdf].
- [6] NIOSH [1994]. Carbon black: Method 5000. In: Eller PM, Cassinelli ME, eds. NIOSH manual of analytical methods. 4th ed. Cincinnati, OH: U.S. Department of Health and Human Services, Centers for Disease Control and Prevention, National Institute for Occupational Safety and Health, DHHS (NIOSH) Publication No. 94-113 [www.cdc.gov/niosh/nmam/].
- [7] NIOSH [1994]. Particulates not otherwise regulated, total: Method 0500. In: Eller PM, Cassinelli ME, eds. NIOSH manual of analytical methods. 4th ed. Cincinnati, OH: U.S. Department of Health and Human Services, Centers for Disease Control and Prevention, National Institute for Occupational Safety and Health, DHHS (NIOSH) Publication No. 94-113 [www.cdc.gov/niosh/nmam/].
- [8] NIOSH [2015]. Particulates not otherwise regulated, total: Method 0501. In: Ashley KE, O'Connor PF, eds. NIOSH manual of analytical methods. 5th ed. Cincinnati, OH: U.S. Department of Health and Human Services, Centers for Disease Control and Prevention, National Institute for Occupational Safety and Health, DHHS (NIOSH) Publication No. 2014-151. [www.cdc.gov/niosh/nmam/].
- [9] OSHA [2003]. Gravimetric determination: PV2121. In: Monitoring methods used by OSHA. Salt Lake City, UT: U.S. Department of Labor, Occupational Safety and Health Administration. [https://www.osha.gov/dts/sltc/methods/partial/pv2121/pv2121.html] (Date accessed: February, 2015).
- [10] O'Connor S, O'Connor PF, Feng HA, Ashley K [2014]. Gravimetric analysis of particulate matter using air samplers housing internal filtration capsules. Gefahrsstoffe Reinh Luft *75*: 403-410.

# METHOD WRITTEN BY: Kevin Ashley, Ph.D., NIOSH/DART

Disclaimer: Mention of any company or product does not constitute endorsement by NIOSH. In addition, citations to websites external to NIOSH do not constitute NIOSH endorsement of the sponsoring organizations or their programs or products. Furthermore, NIOSH is not responsible for the content of these websites. All web addresses referenced in this document were accessible as of the publication date.