

ORAU TEAM Dose Reconstruction Project for NIOSH

Oak Ridge Associated Universities I Dade Moeller I MJW Technical Services Page 1 of 73

DOE Review Release 07/23/2014

Guiding Reconstruction of Intakes of Thorium Resulting from Nuclear Weapons Programs		ORAUT-OTIB-0076 Effective Date: Supersedes:		Rev. 00 07/10/2014 None	
Subject Expert(s):	Thomas R. LaBone				
Document Owner Approval:	Signature on File Thomas R. LaBone, Document Owner		Approval Date	:	06/24/2014
Concurrence:	Signature on File John M. Byrne, Objective 1 Manager		Concurrence E	Date:	06/25/2014
Concurrence:	Signature on File Edward F. Maher, Objective 3 Manager		Concurrence E	Date:	06/24/2014
Concurrence:	Dianne Poncio Signature on Fil Kate Kimpan, Project Director	e for	Concurrence E	Date:	06/24/2014
Approval: Signature on File James W. Neton, Associate Director for		Science	Approval Date	:	07/10/2014

🖂 New	Total Rewrite	Page Change

FOR DOCUMENTS MARKED AS A TOTAL REWRITE, REVISION, OR PAGE CHANGE, REPLACE THE PRIOR REVISION AND DISCARD / DESTROY ALL COPIES OF THE PRIOR REVISION.

Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 2 of 73
------------------------------	-----------------	----------------------------	--------------

PUBLICATION RECORD

EFFECTIVE	REVISION	
DATE	NUMBER	DESCRIPTION
07/10/2014	00	New technical information bulletin to detail how to evaluate chest counts, whole-body counts, and various types of urine samples after intakes of ²³² Th. Incorporates formal internal and NIOSH review comments. Training required: As determined by the Objective Manager. Initiated by Thomas R. LaBone.

		TABLE OF CONTENTS	
<u>SECTI</u>	ION	TITLE	<u>PAGE</u>
Acrony	yms and	d Abbreviations	7
1.0	Introdu 1.1 1.2	uction Purpose Background	8 8 8
2.0	Equilib 2.1 2.2	orium and Shared Kinetics Chest and Whole-body Counts Urine	9 9 10
3.0	Disequ 3.1 3.2	uilibrium and Shared Kinetics Chest and Whole-body Counts Urine Bioassay	11 11 14
4.0	Exact 4.1	Calculations Assuming Independent Kinetics Urine Bioassay	15 19
5.0	Chroni 5.1	ic Intakes Urine Bioassay	22 24
6.0	Using	IMBA for Efficiency Calculations	25
7.0	Using 7.1 7.2	IMBA for Chest CountsAcute Intakes.7.1.17.1.2Adjustment of Thorium Intakes.7.1.3Guidance for Acute IntakesChronic Intakes7.2.1Adjustment of Chronic Thorium Intakes.7.2.2Guidance for Chronic Intakes	25 27 29 30 30 32 35
8.0	Using 8.1 8.2	IMBA for Whole-Body Counts Acute Intakes 8.1.1 Triple-Separated Thorium Mixture 8.1.2 Adjustment of Thorium Intakes 8.1.3 Guidance for Acute Intakes Chronic Intakes 8.2.1 Adjustment of Chronic Thorium Intakes 8.2.1 Adjustment of Chronic Intakes 8.2.2 Guidance for Chronic Intakes	36 36 37 39 40 40 42 43
9.0	Using 9.1 9.2	IMBA for Total Thorium in Urine Acute Intakes 9.1.1 Triple-Separated Thorium Mixture 9.1.2 An Additional Approximation 9.1.3 Guidance for Acute Intakes Chronic Intakes Ovidence for Observice Intakes	45 45 47 48 48 49 50
10.0	Using	9.2.1 Guidance for Unronic Intakes IMBA for Thorium-228 in Urine	53

Revision No. 00

Effective Date: 07/10/2014

Page 3 of 73

Document No. ORAUT-OTIB-0076

Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 4 of 73

	10.1	Acute Ir 10.1.1	ntakes Triple-Separated Thorium Mixture	
	10.2	10.1.2 Chronic	Guidance for Acute Intakes	
	10.2	10.2.1	Guidance for Chronic Intakes	
11.0	Attribu	utions and	d Annotations	
Refere	ences			

ATTACHMENT A, S	STANDARD THORIUM MIXTURES	61
ATTACHMENT B, C	OBTAINING CHRONIC INTAKE IRFs FROM ACUTE INTAKE IRFs	67
ATTACHMENT C, S	SUMMARY OF GUIDANCE FOR ASSESSING THORIUM INTAKES FROM	
E	BIOASSAY	72

LIST OF TABLES

TABLE

<u>TITLE</u>

<u>PAGE</u>

<u>PAGE</u>

A-1	Ratios of ²²⁸ Th to ²³² Th activities for secular equilibrium and after one, two, and three	
	chemical separations	.65
A-2	Relative amounts of ²³² Th, ²²⁸ Ra, and ²²⁸ Th in single separated thorium as a function of	
	time since separation	. 66

LIST OF FIGURES

FIGURE

<u>TITLE</u>

1-1	First eight members of the ²³² Th decay chain	8
3-1	Activity of ²²⁸ Th present as a function of time after chemical purification of 1 Bq of ²³² Th	
	in equilibrium with its progeny	11
3-2	Radium-228 and ²²⁴ Ra present as a function of time after chemical purification of 1 Bq	
	of ²³² Th in equilibrium with its progeny	12
4-1	Chest burdens of ²³² Th, ²²⁸ Ac, and ²¹² Pb after a unit acute inhalation intake of pure	
	Type S ²³² Th	16
4-2	Chest burdens of ²²⁸ Ra, ²²⁸ Ac, and ²¹² Pb after a unit acute inhalation intake of pure	
	Type S ²²⁸ Ra	16
4-3	Chest burdens of ²²⁸ Th and ²¹² Pb after a unit acute inhalation intake of pure Type S	
	²²⁸ Th	16
4-4	Chest burdens of ²²⁴ Ra and ²¹² Pb after a unit acute inhalation intake of pure Type S	
	²²⁴ Ra	17
4-5	Thorium-232 and ²²⁸ Th in a 24-hour incremental urine sample after a unit acute	
	inhalation intake of pure Type S ²³² Th	20
4-6	Radium-228 and ²²⁸ Th in a 24-hour incremental urine sample after a unit acute	
	inhalation intake of pure Type S ²²⁸ Ra	20
4-7	Thorium-228 in a 24-hour incremental urine sample after a unit acute inhalation intake	
	of pure Type S ²²⁸ Th	21
	• • • •	

Doc	ument No. ORAUT-OTIB-0076 Revision No. 00 Effective Date: 07/10/2014 Page 5 of 73
7-1	Lead-212 chest burden after an acute inhalation intake of Type S thorium having a ²²⁸ Th to ²³² Th ratio of 1:1
7-2	Lead-212 chest burden after an acute inhalation intake of Type S thorium having a ²²⁸ Th to ²³² Th ratio of 0.19:1
7-3	Lead-212 chest burden after an acute inhalation intake of Type M thorium having a ²²⁸ Th to ²³² Th ratio of 0.19:1
7-4	Lead-212 chest burden after an acute inhalation intake of Type S thorium having a 228 Th to 232 Th ratio of 0.19:1 with vertical dashed line at $t = 30$ days after intake
7-5	Lead-212 chest burden after an acute inhalation intake of Type M thorium having a 228 Th to 232 Th ratio of 0.19:1 with vertical dashed line at <i>t</i> = 30 days after intake
7-6	Lead-212 chest burden after a chronic inhalation intake of Type S thorium having a ²²⁸ Th to ²³² Th ratio of 0.19:1
7-7	Lead-212 chest burden after a chronic inhalation intake of Type M thorium having a ²²⁸ Th to ²³² Th ratio of 0.19:1
7-8	Lead-212 chest burden during and after a 365-day chronic inhalation intake of Type S thorium having a ²²⁸ Th to ²³² Th ratio of 0.19:1
7-9	Lead-212 chest burden during and after a 1,000-day chronic inhalation intake of Type S thorium having a ²²⁸ Th to ²³² Th ratio of 0.19:1
7-10	Lead-212 chest burden during and after a 5,000-day chronic inhalation intake of Type S thorium having a ²²⁸ Th to ²³² Th ratio of 0,19·1
7-11	Lead-212 chest burden during and after a 365-day chronic inhalation intake of Type M thorium having a ²²⁸ Th to ²³² Th ratio of 0 19:1
7-12	Lead-212 chest burden during and after a 1,000-day chronic inhalation intake of Type M thorium having a 228 Th to 232 Th ratio of 0.19:1
7-13	Lead-212 chest burden during and after a 5,000-day chronic inhalation intake of Type M thorium having a ²²⁸ Th to ²³² Th ratio of 0,19:1
8-1	Lead-212 whole-body burden after an acute inhalation intake of Type S thorium having a ²²⁸ Th to ²³² Th ratio of 1:1
8-2	Lead-212 whole-body burden after an acute inhalation intake of Type S thorium having a ²²⁸ Th to ²³² Th ratio of 0 19:1
8-3	Lead-212 whole-body burden after an acute inhalation intake of Type M thorium having a ²²⁸ Th to ²³² Th ratio of 0.19:1
8-4	Lead-212 whole-body burden after an acute inhalation intake of Type S thorium having a^{228} Th to 232 Th ratio of 0.19:1 with vertical dashed line at $t = 30$ days after intake 39
8-5	Lead-212 whole-body burden after an acute inhalation intake of Type M thorium having a^{228} Th to a^{232} Th ratio of 0.19:1 with vertical dashed line at $t = 30$ days after intake 40
8-6	Lead-212 whole-body burden after a chronic inhalation intake of Type S thorium having a ²²⁸ Th to ²³² Th ratio of 0 19:1
8-7	Lead-212 whole-body burden after a chronic inhalation intake of Type M thorium having a 228 Th to 232 Th ratio of 0.19:1
8-8	Lead-212 whole-body burden during and after a 365-day chronic inhalation intake of Type S thorium having a 228 Th to 232 Th ratio of 0.19:1
8-9	Lead-212 whole-body burden during and after a 1,000-day chronic inhalation intake of Type S thorium baying a ²²⁸ Th to ²³² Th ratio of 0 19:1
8-10	Lead-212 whole-body burden during and after a 5,000-day chronic inhalation intake of Type S thorium having a ²²⁸ Th to ²³² Th ratio of 0 19:1
8-11	Lead-212 whole-body burden during and after a 365-day chronic inhalation intake of 2^{228} Th to 2^{232} Th ratio of 0.19.1
8-12	Lead-212 whole-body burden during and after a 1,000-day chronic inhalation intake of
8-13	Lead-212 whole-body burden during and after a 5,000-day chronic inhalation intake of Type M thorium having a ²²⁸ Th to ²³² Th ratio of 0.19:1
	··· · · · · · · · · · · · · · · · · ·

Doc	ument No. ORAUT-OTIB-0076 Revision No. 00 Effective Date: 07/10/2014 Page 6 of 7	'3
9-1	Thorium in 24-hour incremental urine samples after an acute inhalation intake of Type S thorium having a 228 Th to 232 Th ratio of 1:1	45
9-2	Thorium urine content after an acute inhalation intake of Type S thorium having a ²²⁸ Th to ²³² Th ratio of 0.19:1	47
9-3	Thorium urine content after an acute inhalation intake of Type S thorium having a ²²⁸ Th to ²³² Th ratio of 0.19:1 showing excretion with Approximation A and with	
9-4	Approximations A and B Thorium urine content after an acute inhalation intake of Type M thorium having a ²²⁸ Th to ²³² Th ratio of 0.19:1 showing excretion with Approximation A and with	50
9-5	Approximations A and B Thorium urine content after a chronic inhalation intake of Type S thorium having a ²²⁸ Th to ²³² Th ratio of 0.19:1	50 51
9-6	Thorium urine content after a 365-day chronic inhalation intake of Type S thorium having a ²²⁸ Th to ²³² Th ratio of 0.19:1	52
9-7	Thorium urine content after a 1,000-day chronic inhalation intake of Type S thorium having a ²²⁸ Th to ²³² Th ratio of 0.19:1	53
9-8	Thorium urine content after a 365-day chronic inhalation intake of Type M thorium having a ²²⁸ Th to ²³² Th ratio of 0.19:1	53
9-9	Thorium urine content after a 1,000-day chronic inhalation intake of Type M thorium having a ²²⁸ Th to ²³² Th ratio of 0.19:1	54
10-1	Thorium-228 in 24-hour incremental urine samples after an acute inhalation intake of Type S thorium having a ²²⁸ Th to ²³² Th ratio of 1:1	54
10-2	Thorium-228 urine content after an acute inhalation intake of Type S thorium having a ²²⁸ Th to ²³² Th ratio of 0.19:1	56
10-3	Thorium-228 urine content after a chronic inhalation intake of Type S thorium having a ²²⁸ Th to ²³² Th ratio of 0.19:1	58
A-1	Thorium-232 and ²²⁰ Th present as a function of time after separation of thorium from other elements in the decay chain	62
A-2	Thorium-232, ^{22°} Ra, and ²²⁴ Ra present after separation of thorium from other elements in the decay chain	63
A-3	Thorium-232 and ²²⁰ Th present as a function of time after a second separation of thorium from other elements in the decay chain	63
A-4	Thorium-232, ²²⁰ Ra, and ²²⁴ Ra present as a function of time after a second separation of thorium from other elements in the decay chain	64
A-5	I horium-232 and ²²⁰ I h present as a function of time after a third separation of thorium from other elements in the decay chain	64
A-6	Thorium-232, ²²⁰ Ra, and ²²⁴ Ra present as a function of time after a third separation of thorium from other elements in the decay chain	65
B-1	Plot of whole-body retention versus time after an acute uptake of the hypothetical radioactive material	68
B-2	Plot of whole-body retention versus time for a constant chronic uptake	70

ACRONYMS AND ABBREVIATIONS

AMAD	activity median aerodynamic activity
Bq	becquerel
d DOE	day Department of Energy
hr	hour
ICRP IMBA IRF	International Commission on Radiological Protection Integrated Modules for Bioassay Analysis intake retention factor
Μ	moderate absorption type
nCi NIOSH	nanocurie National Institute for Occupational Safety and Health
ORAU	Oak Ridge Associated Universities
pCi	picocurie
s S SRDB Ref ID	second slow absorption type Site Research Database Reference Identification (number)
TIB	technical information bulletin
yr	year
U.S.C.	United States Code
μm	micrometer
§	section or sections

Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 8 of 73

1.0 INTRODUCTION

Technical information bulletins (TIBs) are not official determinations made by the National Institute for Occupational Safety and Health (NIOSH) but are rather general working documents that provide historical background information and guidance to assist in the preparation of dose reconstructions at particular sites or categories of sites. They will be revised in the event additional relevant information is obtained about the affected site(s). TIBs may be used to assist NIOSH staff in the completion of individual dose reconstructions.

In this document, the word "facility" is used as a general term for an area, building, or group of buildings that served a specific purpose at a site. It does not necessarily connote an "atomic weapons employer facility" or a "Department of Energy (DOE) facility" as defined in the Energy Employees Occupational Illness Compensation Program Act of 2000 [42 U.S.C. § 7384I(5) and (12)].

1.1 PURPOSE

The purpose of this report is to detail how to evaluate chest counts, whole-body counts, and various types of urine samples after intakes of ²³²Th. The computational methods for this TIB used the DCAL software and properly accounted for disequilibrium and independent kinetics. In addition, methods are offered that allow conservative approximations to the exact solutions to be made with existing Project software [i.e., Integrated Modules for Bioassay Analysis (IMBA)].

1.2 BACKGROUND

Thorium-232 is a long-lived radionuclide that has a decay chain with 10 progeny that are themselves radioactive. Figure 1-1 shows the first eight members of the chain. Evaluating bioassay data to calculate intakes of ²³²Th and its progeny can be one of the most challenging tasks in internal dosimetry. The primary challenges are caused by disequilibrium of the ²³²Th decay chain and independent biokinetics of the members of the decay chain.



Equilibrium versus Disequilibrium

Thorium-232 confined in one place with its progeny will eventually come into "secular equilibrium" (i.e., the activity of all members of the decay chain will be equal to that of the parent ²³²Th). As this document shows, equilibrium makes it relatively easy to estimate intakes from bioassay data.

Chemical processing separates the members of the decay chain based on what element they are, disrupt this equilibrium, and cause the progeny to be present in varying amounts that change over time. This "disequilibrium" complicates evaluation of bioassay data because dose reconstructors usually have to specify the nature of the disequilibrium to evaluate bioassay data.

Shared versus Independent Kinetics

"Shared kinetics" refers to the assumption that all members of the decay chain have the same biokinetics as ²³²Th (i.e., all progeny are transported, deposited, and retained in the body just like the parent). Shared kinetics are used in the International Commission on Radiological Protection (ICRP) Publication 30 biokinetic models for thorium (ICRP 1979-1988).

"Independent kinetics" refers to the assumption that all members of the decay chain have biokinetics based on the element. For example, ²³²Th has the biokinetics of thorium until it decays to ²²⁸Ra, at

Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 9 of 73

which point is has the biokinetics of radium (thorium and radium have very different biokinetics). Independent kinetics are used in the newer ICRP Publication 68 biokinetic models (ICRP 1995), which are the models the NIOSH Project uses to evaluate bioassay data. Independent kinetics complicates the evaluation of bioassay data because IMBA does not support independent kinetics for the ²³²Th chain. However, the DCAL¹ software does properly account for independent kinetics and was used for this analysis to obtain exact solutions.

2.0 EQUILIBRIUM AND SHARED KINETICS

2.1 CHEST AND WHOLE-BODY COUNTS

Thorium-232 and ²²⁸Th do not emit photon radiation that is useful for quantifying the thorium in the body with in vivo bioassay (chest or whole-body counting). For this reason, in vivo bioassay for ²³²Th is often performed by quantifying the activity of the ²²⁸Ac or ²¹²Pb progeny in the body and then calculating the amount of ²³²Th (and relatively long-lived progeny ²²⁸Ra and ²²⁸Th) present by assuming the material is in secular equilibrium. This is considered to be a reasonable approach when:

- The inhaled thorium has been locked in an insoluble physical matrix for a long period (e.g., for natural thorium mined from the ground), and
- The inhaled thorium particulate does not dissolve in the lungs to any great extent.

Example 2-1

For example, assume that a person inhaled 1 nCi of 5- μ m activity median aerodynamic activity (AMAD) Type S ²³²Th in equilibrium with its progeny. IMBA and DCAL can be used to calculate² the ²³²Th chest burden, denoted here as $q_{th232}(t)$, where *t* is time in days. At 100 days after the intake it would be:

$$q_{\text{th}232}(100) = 3.670\text{E}-02\text{nCi}$$
 (per nCi intake of ²³²Th) (2-1)

Note that the intake retention fraction (IRF), denoted here as $m_{\text{th}232}(t)$, is:

$$m_{\text{th}232}(100) = \frac{q_{\text{th}232}(100)}{\ln\text{Ci}}$$
(2-2)

at t = 100 days after the intake. The discussion in this report uses both IRFs and burdens to develop the concepts.

Under the stated conditions, equilibrium implies that the chest burdens of all the progeny of ²³²Th, including that of ²¹²Pb (q_{ob212}), are the same as the parent ²³²Th chest burden:

$$q_{\text{pb212}}(100) = 3.670\text{E}-02\text{nCi}$$
 (per nCi intake of ²³²Th) (2-3)

http://www.epa.gov/radiation/assessment/dcal.html.

² DCAL was used for all calculations for this report. DCAL and IMBA produce similar results in situations where both are applicable. For example, the burden per unit intake IMBA calculated in this case is 3.666E-2 nCi per nCi intake of ²³²Th.

Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 10 of 73

If a chest burden of 10 nCi of ²¹²Pb was measured at 100 days after an acute inhalation intake, the intake of ²³²Th (I_{th232}) is:

$$I_{\text{th232}} = \left(\frac{10\text{nCi}}{m_{\text{pb212}}(100)}\right) = \left(\frac{10\text{nCi}}{m_{\text{th232}}(100)}\right) = \left(\frac{10\text{nCi}}{3.67\text{E-2}}\right) = 272.5\text{nCi}$$
(2-4)

The intake of each progeny of ²³²Th is equal to the intake of ²³²Th. For a measured a chest burden of 10 nCi of ²²⁸Ac instead of 10 nCi of ²¹²Pb, the resulting ²³²Th intake estimate would be the same as above. The evaluation of whole-body count data is completely analogous to the evaluation of chest count data, the only difference being that whole-body burdens are substituted for the chest burdens.

2.2 URINE

Thorium in urine is typically quantified using one of the following three analyses:

- Isotopic thorium (²³²Th and ²²⁸Th activities reported separately),
- Total thorium (sum of ²³²Th and ²²⁸Th activity reported), and
- ²²⁸Th (only ²²⁸Th activity reported).

Assuming equilibrium and shared kinetics makes the evaluation of thorium urine bioassay results relatively straightforward because the ²³²Th and/or ²²⁸Th are measured directly.

Example 2-2

Assume that a person inhaled 10 pCi of 5- μ m AMAD Type S ²³²Th in equilibrium with its progeny. We can calculate that at 100 days after this intake the person would have a 24-hour urine sample containing:

$$q_{\text{th}232}(100) = 3.650\text{E}-06\,\text{pCi}$$
 (per 10 pCi intake of ²³²Th) (2-5)

Note that this is an incremental 24-hour urine sample and by convention it was <u>completed</u> at 100 days after the intake. If 10 pCi of ²³²Th is measured in the urine, the intake of ²³²Th is:

$$I_{\text{th}232} = \left(\frac{10\text{pCi}}{m_{\text{th}232}(100)}\right) = \left(\frac{10\text{pCi}}{3.650\text{E-07}}\right) = 2.740\text{E+07}\text{pCi}$$
(2-6)

where $m_{\text{th}232}$ is the IRF for ²³²Th in a 24-hour urine sample.

Example 2-3

If 10 pCi of ²²⁸Th is measured in the urine, the intake of ²³²Th is:

$$I_{\text{th232}} = \left(\frac{10\text{pCi}}{m_{\text{th228}}(100)}\right) = \left(\frac{10\text{pCi}}{m_{\text{th232}}(100)}\right) = \left(\frac{10\text{pCi}}{3.650\text{E-7}}\right) = 2.740\text{E+07}\text{pCi}$$
(2-7)

Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 11 of 73
------------------------------	-----------------	----------------------------	---------------

Example 2-4

If 10 pCi of total thorium is measured in the urine, the intake of total thorium is:

$$I_{\rm th} = \left(\frac{5\,{\rm pCi}}{m_{\rm th232}\,(100)}\right) + \left(\frac{5\,{\rm pCi}}{m_{\rm th228}\,(100)}\right) = \left(\frac{10\,{\rm pCi}}{m_{\rm th232}\,(100)}\right) = 2.740\,{\rm E} + 07\,{\rm pCi}$$
(2-8)

This calculation assumes that half of the total thorium activity in the urine is ²³²Th and half is ²²⁸Th. The intakes of ²³²Th and ²²⁸Th are therefore:

$$I_{\text{th}232} = I_{\text{th}228} = 0.5I_{\text{th}} = 1.370\text{E}+07\,\text{pCi}$$
 (2-9)

where I_{th} is the total thorium intake activity.

3.0 DISEQUILIBRIUM AND SHARED KINETICS

3.1 CHEST AND WHOLE-BODY COUNTS

Thorium that has been chemically purified consists primarily of ²³²Th and ²²⁸Th. Progeny that are not isotopes of thorium are absent immediately after purification and begin to grow in. The progeny can exist in various degrees of disequilibrium with the parent ²³²Th depending on the timing and number of separations. For example, the plot in Figure 3-1 shows the activity of ²²⁸Th present as a function of time after a chemical separation that removes all of the nonthorium isotopes. Immediately after the separation the ratio of ²²⁸Th to ²³²Th is 1:1, but it decreases to a minimum of 1:0.422 at 4.55 years after separation. This behavior is the result of the ²²⁸Ra being removed from the material and its subsequent in growth.



Figure 3-1. Activity (Bq) of ²²⁸Th (red line) present as a function of time after chemical purification of 1 Bq of ²³²Th in equilibrium with its progeny.

The ingrowth curves for ²²⁸Ra and ²²⁴Ra are shown in Figure 3-2. These two progeny are important because ²¹²Pb (which can be measured in vivo) is in equilibrium with the ²²⁴Ra, and ²²⁸Ac (also in vivo)

Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 12 of 73

measurable) is in equilibrium with the ²²⁸Ra. Therefore, we can use ²¹²Pb to quantify the ²²⁸Th present and ²²⁸Ac to quantify the ²²⁸Ra present. In addition, note that the minimum in the ²²⁸Th:²³²Th curve in Figure 3-1 is always greater than zero, whereas the minimum of the ²²⁸Ra:²³²Th curve in Figure 3-2 is zero. The practical consequences of all this are:

- If there is ²¹²Pb present, there is always ²²⁸Th and ²³²Th present. Even though the exact activity of ²³²Th is unknown, it is feasible to come up with a conservative estimate based on the ²¹²Pb.
- If there is ²²⁸Ac present, there might or might not be ²³²Th present because the ²²⁸Ra parent of ²²⁸Ac has a half-life long enough to exist independently of the ²³²Th. It is difficult to come up with a conservative estimate of the ²³²Th based on the ²²⁸Ac because there is no nonzero minimum in the ingrowth curve.



Figure 3-2. Radium-228 (blue line) and ²²⁴Ra (red line) present as a function of time after chemical purification of 1 Bq of ²³²Th in equilibrium with its progeny. Note that the ²²⁴Ra curve is basically the same as the ²²⁸Th curve in Figure 3-1.

In summary, to properly interpret a ²¹²Pb or ²²⁸Ac chest count in terms of the ²³²Th intake, the dose reconstructor needs to know something about the relative amounts of the ²³²Th progeny in the material. This information is usually derived from a knowledge of the separation history of the material and a liberal application of the Bateman equations. To facilitate dose reconstructions based on ²¹²Pb, four standard thorium mixtures are used (see Appendix A):

- Unseparated (equilibrium) thorium, which has a 1:1 ²²⁸Th to ²³²Th ratio;
- Single-separated thorium, which has a 0.42:1 ²²⁸Th to ²³²Th ratio;
- Double-separated thorium, which has a 0.26:1 ²²⁸Th to ²³²Th ratio; and
- Triple-separated thorium, which has a 0.19:1 ²²⁸Th to ²³²Th ratio.

There are two important points to make about these standard mixtures. First, once a mixture is selected for a particular application, it is assumed to be a constant and does not change as a function of time. For example, if a worker is assumed to be chronically exposed to triple-separated thorium in

	Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 13 of 73
--	------------------------------	-----------------	----------------------------	---------------

a facility from 1980 to 1995, then the same mixture applies for the entire exposure period; that is, there is no ingrowth of ²²⁸Th during the 15 years. Second, the mixtures define the relative amounts of ²³²Th and ²²⁸Th but not any of the other members of the decay chain. More specifically, these thorium mixtures do not contain any ²²⁸Ra.

Analogous standard thorium mixtures for evaluating ²²⁸Ac chest counts are discussed in Attachment A. In practice, the age of the thorium (i.e., the years since separation) must be specified to interpret an ²²⁸Ac chest count.

Example 3-1

Assume that after a chemical separation the thorium is fabricated into an insoluble material, which is inhaled by a worker. Assuming the worker inhaled 5- μ m AMAD Type S single-separation thorium, the exact expression for the ²¹²Pb chest burden of 10 nCi is given by:

$$q_{pb212}(100) = 10 \,\text{nCi} = I_{th232} m_{pbth232}(100) + I_{th228} m_{pbth228}(100)$$
(3-1)

where $m_{\text{pbth228}}(t)$ is the IRF for ²¹²Pb that grows in from the ²²⁸Th intake and $m_{\text{pbth232}}(t)$ is the IRF for the ²¹²Pb that grows in from the ²³²Th. Based on the discussion above and that in Attachment A, the following assumptions are used:

$$m_{\text{pbth228}}\left(t\right) = m_{\text{th228}}\left(t\right) \tag{3-2}$$

$$m_{\text{pbth}232}(t) = 0^{3}$$
 (3-3)

$$\frac{I_{\text{th}228}}{I_{\text{th}232}} = 0.42 \tag{3-4}$$

Therefore, the intake of ²²⁸Th simplifies to:

$$I_{\text{th228}} = \left(\frac{10\text{nCi}}{m_{\text{th228}}(100)}\right) = \left(\frac{10\text{nCi}}{(3.320\text{E}-02)}\right) = 3.012\text{E}+02\text{nCi}$$
(3-5)

The ²³²Th intake is equal to $301.2 \div 0.42 = 717.2$ nCi, but the intakes of all other ²³²Th progeny are 0 nCi. This intake estimate is relatively insensitive to the time that has elapsed since separation (i.e., the age of the thorium) and is a conservative intake estimate as long as the thorium has only been processed once.

Example 3-2

If we had measured 10 nCi of ²²⁸Ac 100 days after an acute inhalation of thorium (thorium in general), the exact expression for the ²²⁸Ac chest burden would be:

$$10nCi = I_{th232}m_{acth232}(100) + I_{ra228}m_{acra228}(100)$$
(3-6)

where $m_{acth232}(t)$ is the IRF for ²²⁸Ac that grows in from the ²³²Th intake, and $m_{acra228}(t)$ is the IRF for ²²⁸Ac that grows in from the ²²⁸Ra intake.

³ Because of the long physical half life of ²³²Th there is negligible ingrowth of ²¹²Pb.

	Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 14 of 73
--	------------------------------	-----------------	----------------------------	---------------

Single-separation thorium is assumed to contain no ²²⁸Ra, so the second term is equal to zero:

$$10nCi = I_{th232} m_{acth232} (100)$$
(3-7)

The intake is therefore:

$$I_{\text{th232}} = \left(\frac{10\,\text{nCi}}{m_{\text{acth232}}\left(100\right)}\right) = \left(\frac{10\,\text{nCi}}{1.190\text{E-03}}\right) = 8.403\text{E+03}\,\text{nCi}$$
(3-8)

This is a rather large intake of ²³²Th given a modest 10-nCi ²²⁸Ac chest burden. The IRF for ²²⁸Ra/²²⁸Ac that grows in from ²³²Th is very sensitive the time that has elapsed since separation, and there is no conservative time that can be specified that is applicable for all situations. This means that the time since separation has to be specified in the evaluation of ²²⁸Ac chest count data. This is in contrast to the evaluation of ²¹²Pb chest counts, where conservative mixtures and times can be specified that are applicable to all situations.

3.2 URINE BIOASSAY

The standard disequilibrium mixtures are easily incorporated into the urine bioassay calculations.

Example 3-3

Continuing the previous example with Type S single-separation thorium, if 10 pCi of ²³²Th is measured in the urine, the intakes of ²³²Th and ²²⁸Th are:

$$I_{\text{th}232} = \left(\frac{10\text{pCi}}{m_{\text{th}232}(100)}\right) = 2.740\text{E}+07\text{pCi}$$
(3-9)

$$I_{\text{th}228} = 0.42I_{\text{th}232} = 1.151\text{E}+07\text{pCi}$$
 (3-10)

Example 3-4

If 10 pCi of ²²⁸Th is measured in the urine, the intakes of ²²⁸Th and ²³²Th are:

$$I_{\text{th228}} = \left(\frac{10\,\text{pCi}}{m_{\text{th228}}\,(100)}\right) = \left(\frac{10\,\text{pCi}}{3.310\text{E-07}}\right) = 3.021\text{E+07}\,\text{pCi}$$
(3-11)

and:

$$I_{\text{th}232} = \frac{I_{\text{th}228}}{0.42} = 7.193\text{E} + 07\text{pCi}$$
 (3-12)

Example 3-5

There are 10 pCi of total thorium measured in the urine. Given that:

$$I_{\text{th}232}m_{\text{th}232}(100) + I_{\text{th}228}m_{\text{th}228}(100) = 10\,\text{pCi}$$
(3-13)

Document No. ORAUT-OTIB-0076 Revisio	on No. 00 Effective Date	e: 07/10/2014 Page 15 of 7	73
--	----------------------------	------------------------------	----

and:

$$\frac{I_{\text{th}228}}{I_{\text{th}232}} = 0.42 \tag{3-14}$$

then the ²³²Th intake is :

$$I_{\text{th}232} = \frac{10 \text{pCi}}{m_{\text{th}232} (100) + 0.42 m_{\text{th}228} (100)}$$
$$= \frac{10 \text{pCi}}{(3.650\text{E}-07) + 0.42 (3.310\text{E}-07)}$$
$$= 1.984\text{E}+07 \text{ pCi}$$
(3-15)

The intake of ²²⁸Th is:

$$I_{\text{th}228} = 0.42I_{\text{th}232} = 8.333\text{E} + 06\,\text{pCi}$$
 (3-16)

4.0 EXACT CALCULATIONS ASSUMING INDEPENDENT KINETICS

Implicit in the calculations above is the assumption that the ²³²Th and its progeny remain together in the body. This assumption of shared kinetics is reasonable for insoluble thorium particulates in the lung, but once the thorium matrix dissolves and the members of the decay chain become subject to the metabolic processes of the body this assumption is not sufficient over time⁴. The current ICRP biokinetic models for the ²³²Th decay chain account for this by assuming that each element (especially thorium, radium, and radon) follows its own biokinetic model once it is released from or born outside of an insoluble matrix. The progeny of the ²³²Th decay chain are said to have independent kinetics.

All of the calculations up to this point can be performed with burdens from IMBA. From a practical point of view, independent kinetics significantly complicates the calculation of IRFs and evaluation of bioassay data because IMBA employs shared kinetics rather than independent kinetics and can no longer be used in all cases.

The DCAL software is capable of using independent kinetics to calculate burdens of ²¹²Pb, ²²⁸Ac, and ²²⁸Th that are the decay products of radionuclides ahead of them in the decay chain. For example, chest burdens that were calculated with DCAL for unit acute inhalation intakes of 5-µm AMAD Type S materials (²³²Th, ²²⁸Ra, ²²⁸Th, ²²⁴Ra) are shown in Figures 4-1 through 4-4.

⁴ All of the ICRP Publication 30 biokinetic models except for tellurium assumed shared kinetics (ICRP 1979–1988).



Figure 4-1. Chest burdens of ²³²Th, ²²⁰Ac, and ²¹²Pb after a unit acute inhalation intake of pure Type S ²³²Th.

To further refine the calculations, assume that ²³²Th in secular equilibrium with its progeny was inhaled. Of primary concern here are the biokinetics of ²³²Th through ²¹²Pb, ²²⁸Ra through ²¹²Pb, and ²²⁸Th through ²¹²Pb. All other unsupported progeny in the initial intake have half-lives that are short enough to limit their contribution to the observed ²¹²Pb whole-body burden except in the first couple of days after the inhalation. To confirm this, the analysis also examined the ²²⁴Ra through ²¹²Pb decay chain, which should be the most significant of the short-lived chains because of the half-life of ²²⁴Ra. The following discussion provides examples.



Figure 4-2. Chest burdens of ²²⁸Ra, ²²⁸Ac, and ²¹²Pb after a unit acute inhalation intake of pure Type S ²²⁸Ra. The ²²⁸Ac activity is equal to the ²²⁸Ra activity.

Figure 4-3. Chest burdens of 228 Th and 212 Pb after a unit acute inhalation intake of pure Type S 228 Th.

Example 4-1

If the measured chest burden of ²¹²Pb at 100 days after an acute inhalation intake of 5- μ m AMAD Type S material is 10 nCi, what would be the intakes assuming they consisted of four different <u>pure</u> materials?

The quantity of ²¹²Pb present in the chest at time *t* after a unit intake of pure ²³²Th is denoted by $m_{\text{pbth}232}(t)$.

Therefore:

$$m_{\rm obtb232}(100) = 4.640 \text{E}-05$$
 (4-1)



Figure 4-4. Chest burdens of ²²⁴Ra and ²¹²Pb after a unit acute inhalation intake of pure Type S ²²⁴Ra.

and:

$$I_{\text{th232}} = \left(\frac{10\text{nCi}}{m_{\text{pbth232}}(100)}\right) = \frac{10\text{nCi}}{4.640\text{E-05}} = 2.155\text{E+05nCi}$$
(4-2)

For comparison, what would the intake be if the ²¹²Pb and ²³²Th were in secular equilibrium, exhibited shared kinetics, and no ²²⁰Rn was lost from the body?:

$$I = \frac{10 \text{nCi}}{m_{\text{th}232} (100)} = \frac{10 \text{nCi}}{3.670 \text{E} \cdot 02} = 2.725 \text{E} + 02 \text{nCi}$$
(4-3)

Note that the IRF in this equation is for the ²³²Th because the ²¹²Pb is assumed to be present in a quantity equal to that of the ²³²Th. It is of interest to note that this simplistic assumption results in an intake estimate that is lower than the exact estimate by a factor of:

$$\frac{3.670E-02}{4.640E-05} \approx 790 \tag{4-4}$$

Document No. ORAUT-OTIB-0076 Revisi	on No. 00 Effective Da	ate: 07/10/2014 F	Page 18 of 73
-------------------------------------	--------------------------	---------------------	---------------

Here are the exact calculations for the other intakes:

$$I_{\rm ra228} = \frac{10\rm{nCi}}{m_{\rm pbra228}(100)} = \frac{10\rm{nCi}}{2.930\rm{E}\text{-}03} = 3.413\rm{E}\text{+}03\rm{nCi}$$
(4-5)

$$I_{\text{th228}} = \frac{10\text{nCi}}{m_{\text{pbth228}}(100)} = \frac{10\text{nCi}}{3.060\text{E}-02} = 3.268\text{E}+02\text{nCi}$$
(4-6)

$$I_{\rm ra224} = \frac{10\,\rm nCi}{m_{\rm pbra224}\,(100)} = \frac{10\,\rm nCi}{2.280\rm E{-}10} = 4.386\rm E{+}10\rm\,nCi$$
(4-7)

The calculations for whole-body counts are the same as above except whole-body burdens per unit intake are substituted for the chest-burdens per unit intake.

Example 4-2

For the same 10 nCi ²¹²Pb chest burden, what would the intake be if the source material was ²³²Th in equilibrium with its progeny?:

$$I_{\text{th232}}m_{\text{pbth232}}(100) + I_{\text{ra228}}m_{\text{pbra228}}(100) + I_{\text{th228}}m_{\text{pbth228}}(100) = 10\,\text{nCi}$$
(4-8)

The intake of ²²⁸Ra and ²²⁸Th are assumed to equal the intake of ²³²Th because the material is in equilibrium, so this can be simplified to:

$$I_{\text{th232}} \left[m_{\text{pbth232}} \left(100 \right) + m_{\text{pbra228}} \left(100 \right) + m_{\text{pbth228}} \left(100 \right) \right] = 10 \,\text{nCi}$$
(4-9)

which can be rearranged to give the intake:

$$I_{\text{th232}} = \frac{10 \,\text{nCi}}{m_{\text{pbth232}} \left(100\right) + m_{\text{pbra228}} \left(100\right) + m_{\text{pbth228}} \left(100\right)} = 2.978 \text{E} + 02 \,\text{nCi}$$
(4-10)

This means that 297.8 nCi of ²³²Th and 297.8 nCi of each of its progeny was inhaled. The inclusion of ²²⁴Ra does not change the intake estimate because it contributes practically no ²¹²Pb at t = 100 days after intake:

$$I = \frac{10 \text{ nCi}}{m_{\text{pbth232}} (100) + m_{\text{pbra228}} (100) + m_{\text{pbth228}} (100) + m_{\text{pbra224}} (100)} = 2.978\text{E} + 02 \text{ nCi}$$
(4-11)

For the purpose of evaluating ²¹²Pb in vivo counts, only the long-lived radionuclides ²³²Th, ²²⁸Ra, and ²²⁸Th in the source term need to be specified. Attributing any ²¹²Pb contributed by short-lived progeny like ²²⁴Ra would result in an overestimate of the intakes of the dosimetrically significant ²³²Th, ²²⁸Ra, and ²²⁸Th.

Example 4-3

Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 19 of 73

What would the intake be if the source material was ²³²Th with the activity of the ²²⁸Ra in the source material being one-half of the ²³²Th activity and the activity of the ²²⁸Th in the source material being one-quarter of the ²³²Th activity?

$$I_{\text{th232}}\left[m_{\text{pbth232}}\left(100\right) + 0.5m_{\text{pbra228}}\left(100\right) + 0.25m_{\text{pbth228}}\left(100\right)\right] = 10\,\text{nCi}$$
(4-12)

$$I_{\text{th}232} = \frac{10\,\text{nCi}}{m_{\text{pbth}232}\,(100) + 0.5m_{\text{pbra}228}\,(100) + 0.25m_{\text{pbth}228}\,(100)} = 1.092\text{E} + 03\,\text{nCi}$$
(4-13)

This means the inhalation intake consisted of 1,092 nCi of 232 Th, 1,092 ÷ 2 = 546 nCi of 228 Ra, and 1,032 ÷ 4 = 273 nCi of 228 Th. This result is unchanged with the inclusion of 224 Ra.

Example 4-4

What would the intake be if the source material was ²³²Th in equilibrium with its progeny and the measured chest burden was 10 nCi of ²²⁸Ac? Analogous to the way we looked at the ²¹²Pb burdens, we have:

$$I_{\text{th}232}m_{\text{acth}232}(100) + I_{\text{acra}228}m_{\text{pbra}228} = 10\,\text{nCi}$$
 (4-14)

The intake of ²²⁸Ra is assumed to equal the intake of ²³²Th, so this can be simplified to:

$$I_{\text{th}232} \left[m_{\text{acth}232} \left(100 \right) + m_{\text{acra228}} \left(100 \right) \right] = 10 \text{nCi}$$
(4-15)

which can be rearranged to give the intake:

$$I_{\text{th232}} = \frac{10\,\text{nCi}}{m_{\text{acth232}}\left(100\right) + m_{\text{acra228}}\left(100\right)} = \frac{10\,\text{nCi}}{1.19E\text{-}3 + 3.55E\text{-}2} = 2.726\text{E} + 02\,\text{nCi}$$
(4-16)

This means that 272.6 nCi of ²³²Th and 272.6 nCi of each of its progeny was inhaled.

4.1 URINE BIOASSAY

Plots of ²³²Th, ²²⁸Ra, and ²²⁸Th urinary excretion curves calculated with DCAL for unit acute inhalation intakes of 5-µm AMAD Type S materials are shown in Figures 4-5 through 4-7.



Figure 4-5. Thorium-232 and ²²⁸Th in a 24-hour incremental urine sample after a unit acute inhalation intake of pure Type S ²³²Th. Note that IRFs from IMBA can be used to model ²³²Th in urine after a ²³²Th intake.



Figure 4-6. Radium-228 and ²²⁸Th in a 24-hour incremental urine sample after a unit acute inhalation intake of pure Type S ²²⁸Ra.



Figure 4-7. Thorium-228 in a 24-hour incremental urine sample after a unit acute inhalation intake of pure Type S ²²⁸Th. Note that IRFs from IMBA can be used to model ²²⁸Th in urine after a ²²⁸Th intake.

Example 4-5

If 10 pCi of ²³²Th is measured in the urine at 100 days after an acute inhalation intake of 5- μ m AMAD Type S material, the intake of ²³²Th is:

$$I_{\text{th232}} = \left(\frac{10\text{pCi}}{m_{\text{th232}}(100)}\right) = 2.740\text{E} + 07\text{pCi}$$
(4-17)

To get the intakes of the other members of the decay chain like ²³²Th we have to assume a particular mixture. For single-separation thorium the ²²⁸Th intake is:

$$I_{\text{th}228} = 0.42I_{\text{th}232} = 1.151\text{E}+07\text{pCi}$$
 (4-18)

Note that IRFs from IMBA can be used to evaluate ²³²Th in urine.

Example 4-6

Assume that 10 pCi of ²²⁸Th is measured in the urine after an intake of single-separation thorium. It is instructive to look at the excretion function like this:

$$\left[I_{\text{th}232}m_{\text{th}1232}(100) + I_{\text{th}228}m_{\text{th}228}(100)\right] = 10\,\text{pCi}$$
(4-19)

Note that ²²⁸Ra does not contribute to the ²²⁸Th in the urine because it was all removed in the separation process. Given that $m_{\text{thth}_{232}}(100)$ is the amount of ²²⁸Th in the urine at 100 days after an acute inhalation intake of pure ²³²Th, the intake of ²²⁸Th is:

$$I_{\rm th228} = 0.42I_{\rm th232} \tag{4-20}$$

which gives:

$$I_{\text{th232}} \left[m_{\text{thth232}} \left(100 \right) + 0.42 m_{\text{th228}} \left(100 \right) \right] = 10 \text{ pCi}$$
(4-21)

Rearranging and solving this equation gives the ²³²Th intake:

$$I_{\text{th}232} = \left(\frac{10 \text{pCi}}{m_{\text{thth}232} (100) + 0.42 m_{\text{th}228} (100)}\right)$$
$$= \left(\frac{10 \text{pCi}}{(4.640\text{E}-10) + 0.42 (3.310\text{E}-07)}\right)$$
$$= 7.169\text{E} + 07 \text{pCi}$$
(4-22)

The ²²⁸Th intake is:

$$I_{\text{th228}} = 0.42I_{\text{th232}} = 3.011\text{E}+07\,\text{pCi}$$
 (4-23)

Example 4-7

Finally, what are the ²³²Th and ²²⁸Th intakes if there is a measured 10 pCi of total thorium in the urine? As before, the excretion function is:

$$\left[I_{\text{th}232}m_{\text{th}232}(100) + I_{\text{th}232}m_{\text{th}1232}(100) + I_{\text{th}228}m_{\text{th}228}(100)\right] = 10\,\text{pCi}$$
(4-24)

Assuming single-separation thorium, this simplifies to:

$$I_{\text{th}232} \left[m_{\text{th}232} \left(100 \right) + m_{\text{th}th232} \left(100 \right) + 0.42 m_{\text{th}228} \left(100 \right) \right] = 10 \,\text{pCi}$$
(4-25)

Rearranging and solving this equation gives the ²³²Th intake:

$$I_{\text{th}232} = \frac{10\text{pCi}}{m_{\text{th}232}(100) + m_{\text{th}1232}(100) + 0.42m_{\text{th}228}(100)}$$
$$= \frac{10\text{pCi}}{(3.650\text{E}-07) + (4.640\text{E}-10) + 0.42(3.310\text{E}-07)}$$
$$= 1.982\text{E}+07\text{pCi}$$
(4-26)

The ²²⁸Th intake is:

$$I_{\text{th}228} = 0.42I_{\text{th}232} = 8.325\text{E}+06\,\text{pCi}$$
 (4-27)

5.0 CHRONIC INTAKES

DCAL does not generate burdens that result from constant chronic intakes. Methods for calculating chronic intake burdens from acute intake burdens are discussed in Appendix B. The results of these calculations are chronic intake IRFs (denoted by \tilde{m}) such as the one shown below for ²¹²Pb in the chest after an intake of pure ²³²Th:

$$\tilde{m}_{\text{pbth232}}(t,T) \qquad t \ge T$$

where

Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 23 of 73
------------------------------	-----------------	----------------------------	---------------

- T = length of chronic intake period
- t = time that the ²¹²Pb chest burden is measured relative to start of chronic intake

This IRF is interpreted as being the ratio of the amount of ²¹²Pb present in the chest at *t* days after the start of the chronic intake to the <u>total</u> amount of ²³²Th inhaled over the *T*-day chronic intake period. This in contrast to IMBA, where the IRF is interpreted as being the ratio of the amount of ²¹²Pb present in the chest at *t* days after the start of the chronic intake to the <u>intake rate</u> of ²³²Th over the *T*-day chronic intake period.

Example 5-1

As an example, assume a 10-nCi chest burden of ²¹²Pb at 365 days after the start of a 100-day chronic inhalation intake of 5-µm AMAD Type S material. What would be the total intakes if they consisted of the four different <u>pure</u> materials?

$$I_{\text{th232}} = \frac{10\text{nCi}}{\tilde{m}_{\text{pbth232}}(365,100)} = \frac{10\text{nCi}}{3.475\text{E-}04} = 2.878\text{E+}04\text{nCi}$$
(5-1)

$$I_{\rm ra228} = \frac{10 \,\text{nCi}}{\tilde{m}_{\rm pbra228} \left(365,100\right)} = \frac{10 \,\text{nCi}}{6.339 \,\text{E-}03} = 1.578 \,\text{E+}03 \,\text{nCi}$$
(5-2)

$$I_{\text{th228}} = \frac{10\,\text{nCi}}{\tilde{m}_{\text{th228}}\left(365,100\right)} = \frac{10\,\text{nCi}}{1.877\text{E-}02} = 5.327\text{E+}02\,\text{nCi}$$
(5-3)

$$I_{\text{ra224}} = \frac{10\text{nCi}}{\tilde{m}_{\text{ra224}}\left(365,100\right)} = \frac{10\text{nCi}}{4.331\text{E}\cdot30} = 2.309\text{E}+30\text{nCi}$$
(5-4)

The intake rates are given by dividing the respective intakes by 100 days. What would the intake be if the source material was ²³²Th in equilibrium with its progeny? As with the acute intake:

$$\left[I_{\text{th}232}\tilde{m}_{\text{pbth}232}\left(365,100\right) + I_{\text{ra228}}\tilde{m}_{\text{pbra228}}\left(365,100\right) + I_{\text{th}228}\tilde{m}_{\text{pbth}228}\left(365,100\right)\right] = 10\,\text{nCi}$$
(5-5)

Setting the intakes of ²²⁸Ra and ²²⁸Th equal to the intake of ²³²Th and rearranging gives:

$$I_{\text{th}232} = \frac{10 \,\text{nCi}}{\tilde{m}_{\text{pbth}232} \left(365,100\right) + \tilde{m}_{\text{pbra}228} \left(365,100\right) + \tilde{m}_{\text{pbth}228} \left(365,100\right)} = 3.928 \text{E} + 02 \,\text{nCi}$$
(5-6)

The intakes of all the members of the ²³²Th decay chain are equal to the intake of ²³²Th.

Example 5-2

What would the intake be if the source material was ²³²Th with the activity of the ²²⁸Ra in the source material being one-half of the ²³²Th activity and the activity of the ²²⁸Th in the source material being one-quarter of the ²³²Th activity?

$$I_{\text{th232}} = \frac{10 \text{nCi}}{\tilde{m}_{\text{pbth232}} \left(365,100\right) + 0.5 \tilde{m}_{\text{pbra228}} \left(365,100\right) + 0.25 \tilde{m}_{\text{pbth228}} \left(365,100\right)} = 1.218\text{E} + 03 \text{nCi}$$
(5-7)

	Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 24 of 73
--	------------------------------	-----------------	----------------------------	---------------

This means the inhalation intake consisted of 1,218 nCi of 232 Th, 1,218 ÷ 2 = 609 nCi of 228 Ra, and 1218 ÷ 4 = 305 nCi of 228 Th.

Example 5-3

What would the intake be if the ²¹²Pb and ²³²Th were in secular equilibrium, exhibited shared kinetics, and no ²²⁰Rn was lost from the body?

$$I_{\text{th}232} = \frac{10\text{nCi}}{\tilde{m}_{\text{th}232} \left(365,100\right)} = \frac{10\text{nCi}}{2.782\text{E}-02} = 3.595\text{E}+02\text{nCi}$$
(5-8)

Note that the IRF in this equation is for the ²³²Th because the ²¹²Pb is assumed to be present in a quantity equal to that of the ²³²Th.

Example 5-4

What would the intake be if the source material was ²³²Th with the activity of the ²²⁸Ra in the source material being one-half of the ²³²Th and there was a measured 10 nCi of ²²⁸Ac in the chest 365 days after the start of a 100-day chronic intake?

$$I_{\text{th}232} = \frac{10 \text{nCi}}{\tilde{m}_{\text{acth}232} (365,100) + 0.5 \tilde{m}_{\text{acra}228} (365,100)}$$
$$= \frac{10 \text{nCi}}{(2.732\text{E}-03) + 0.5 (2.507\text{E}-02)}$$
$$= 6.549\text{E}+02 \text{nCi}$$
(5-9)

This means the intake consisted of 655 nCi of 232 Th and 655 ÷ 2 = 328 nCi of 228 Ra.

5.1 URINE BIOASSAY

Example 5-5

What are the ²³²Th and ²²⁸Th intakes implied by 10 pCi of total thorium measured in the urine at 365 days after the start of a 100-day chronic intake? As with the acute intake version of this problem, the excretion function is:

$$\left[I_{\text{th}232}\tilde{m}_{\text{th}232}\left(365,100\right) + I_{\text{th}232}\tilde{m}_{\text{th}1232}\left(365,100\right) + I_{\text{th}228}\tilde{m}_{\text{th}228}\left(365,100\right)\right] = 10\,\text{pCi}$$
(5-10)

Assuming single-separation thorium, this simplifies to:

$$I_{\text{th}232} \left[\tilde{m}_{\text{th}232} \left(365,100 \right) + \tilde{m}_{\text{th}th232} \left(365,100 \right) + 0.42 \tilde{m}_{\text{th}228} \left(365,100 \right) \right] = 10 \text{ pCi}$$
(5-11)

|--|

Rearranging and solving this equation gives the ²³²Th intake:

$$I_{\text{th}232} = \frac{10\text{pCi}}{\tilde{m}_{\text{th}232} (365,100) + \tilde{m}_{\text{thth}232} (365,100) + 0.42 \tilde{m}_{\text{th}228} (365,100)}$$
$$= \frac{10\text{pCi}}{(2.896\text{E}-07) + (3.503\text{E}-09) + 0.42 (2.129\text{E}-07)}$$
(5-12)
$$= 2.614\text{E}+07\text{pCi}$$

The ²²⁸Th intake is:

$$I_{\text{th}228} = 0.42I_{\text{th}232} = 1.098\text{E} + 07\,\text{pCi} \tag{5-13}$$

6.0 USING IMBA FOR EFFICIENCY CALCULATIONS

DCAL can be used to perform best-estimate dose reconstructions of thorium intakes based on bioassay data and the resulting organ doses. However, DCAL is not ideal for routine dose reconstructions because it is designed to be used in a batch mode and its output requires further processing with a custom code to obtain chronic intake burdens.

To facilitate <u>efficiency</u> calculations, ways are suggested here to adjust intakes and intake rates that are calculated with IMBA so that they will not underestimate those that are calculated with exact methods based on DCAL. A summary of the efficiency calculations is given in Attachment C. These adjustments can be used to perform efficiency calculations when an overestimate of dose is appropriate and a single measurement is being evaluated (which is typical for missed dose calculations). Efficiency methods using IMBA are not provided for ²²⁸Ac chest counts⁵, which should be evaluated with DCAL. IMBA cannot be used for best estimates of intake and dose, which require the use of DCAL.

7.0 USING IMBA FOR CHEST COUNTS

7.1 ACUTE INTAKES

Assume a mixture of 1 nCi of ²³²Th and 1 nCi of ²²⁸Th (both being 5-µm AMAD Type S material) was inhaled. The ²¹²Pb chest burden as a function of time after the acute intake is shown in Figure 7-1.

⁵ The approximations given in Equations 7-3 and 7-4 that make efficiency calculations feasible for ²¹²Pb do not have valid counterparts for ²²⁸Ac.



Figure 7-1. Lead-212 chest burden after an acute inhalation intake of Type S thorium having a ²²⁸Th to ²³²Th ratio of 1:1.

The exact chest burden q of ²¹²Pb at t days after an acute inhalation intake is given by:

$$q(t) = q_{\text{pbth}232}(t) + q_{\text{pbth}228}(t)$$
(7-1)

where $q_{\text{pbth}232}$ is the chest burden of ²¹²Pb that grows in from the inhaled ²³²Th and $q_{\text{pbth}228}$ is the chest burden of ²¹²Pb that grows in from the inhaled ²²⁸Th.

These exact burdens are calculated with DCAL, which accounts for independent kinetics of the thorium decay chain and the loss of ²²⁰Rn. This relationship can be restated in terms of intakes and IRFs:

$$q(t) = I_{\text{th}232} m_{\text{pbth}232}(t) + I_{\text{th}228} m_{\text{pbth}228}(t)$$
(7-2)

Two approximations can be made:

1. The amount of ²¹²Pb present equals the amount of ²²⁸Th present at all times after the intake:

$$m_{\text{pbth}228}(t) = m_{\text{th}228}(t)$$
 (7-3)

2. There is negligible ingrowth of ²¹²Pb from the ²³²Th component of the intake:

$$m_{\text{pbth232}}\left(t\right) = 0 \tag{7-4}$$

This gives the following approximation to q:

$$q'(t) = I_{\text{th}228} m_{\text{th}228}(t)$$
 (7-5)

where $m_{\text{th}228}$ is the ²²⁸Th chest IRF at time *t* (which can be calculated with IMBA). As seen in the plot above, these approximations provide reasonably accurate estimates of the ²¹²Pb burden between approximately 10 and 1,000 days after the intake.

	Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 27 of 73
--	------------------------------	-----------------	----------------------------	---------------

Example 7-1

For example, assume that a ²¹²Pb chest burden of 1.5 nCi is observed at 100 days after an acute inhalation intake of this thorium. Given a ²²⁸Th:²³²Th ratio of 1: 1, the intake of ²³²Th is:

$$I_{\text{th}232} = \frac{1.5 \text{nCi}}{m_{\text{pbth}232} (100) + m_{\text{pbth}228} (100)}$$
$$= \frac{1.5 \text{nCi}}{(4.640\text{E}-05) + (3.060\text{E}-02)}$$
$$= 4.895\text{E}+01\text{nCi}$$
(7-6)

which translates into 48.95 nCi of ²²⁸Th. These exact intakes (calculated with DCAL) can be checked by calculating the expected ²¹²Pb chest burden to determine if it equals the burden from which the intakes were calculated:

$$1.5nCi = (48.95nCi)(4.64E-05) + (48.95nCi)(0.0306)$$
(7-7)

With the approximate method we have a ²²⁸Th intake of:

$$I = \frac{1.5 \,\mathrm{nCi}}{m_{\mathrm{th}228} \,(100)} = \frac{1.5 \,\mathrm{nCi}}{0.0332} = 45.18 \,\mathrm{nCi}\,,\tag{7-8}$$

which translates into a 45.18 nCi intake of ²³²Th. Note that in this example:

- For a given <u>intake</u> the exact method gives a lower <u>chest burden</u> than does the approximate method at *t* = 100 days (see Figure 7-1).
- However, for a given <u>chest burden</u> the exact method gives a larger <u>intake</u> than does the approximate method.

In practice dose reconstructors typically calculate intakes from chest burdens. Therefore, the plot in Figure 7-1 can be interpreted to mean that the approximate method will underestimate intakes at times before ~300 days after the intake (where the curves cross) and overestimate intakes after that day.

7.1.1 Triple-Separated Thorium Mixture

As noted in Section 3.0, triple-separated thorium has a 228 Th: 232 Th ratio of 0.19:1. Assume a mixture of 1 nCi of 232 Th and 0.19 nCi of 228 Th (both being 5-µm AMAD Type S material) was inhaled. The 212 Pb chest burden as a function of time after the acute intake is shown in Figure 7-2.





Once again, the exact chest burden q of ²¹²Pb at *t* days after an acute inhalation intake is given by:

$$q(t) = I_{\text{th}232} m_{\text{pbth}232}(t) + I_{\text{th}228} m_{\text{pbth}228}(t)$$
(7-9)

and the approximation is:

$$q'(t) = I_{\text{th}228} m_{\text{th}228}(t)$$
(7-10)

Example 7-2

For example, assume that a ²¹²Pb chest burden of 1.5 nCi is observed at 100 days after an acute inhalation intake of this triple-separated Type S thorium. Given a ²²⁸Th:²³²Th ratio of 0.19, the exact intake (calculated with DCAL) of ²³²Th is:

$$I_{\text{th}232} = \frac{1.5 \,\text{nCi}}{m_{\text{pbth}232} \left(100\right) + 0.19 m_{\text{pbth}228} \left(100\right)}$$
$$= \frac{1.5 \,\text{nCi}}{4.64 \text{E} \cdot 05 + \left(0.19\right) \left(0.0306\right)}$$
$$= 255.96 \,\text{nCi}$$
(7-11)

which translates into 0.19 x 255.96 nCi = 48.63 nCi of ²²⁸Th. As a check, it is useful to show that:

$$1.5nCi = (255.96nCi)(4.64E-05) + (48.63nCi)(0.0306)$$
(7-12)

With the approximate method the intake of ²²⁸Th is:

$$I_{\text{th}228} = \frac{1.5\,\text{nCi}}{m_{\text{th}228}\,(100)} = \frac{1.5\,\text{nCi}}{0.0332} = 45.18\,\text{nCi}$$
(7-13)

which gives $45.18 \text{ nCi} \div 0.19 = 237.79 \text{ nCi}$ of 232 Th.

Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 29 of 73
------------------------------	-----------------	----------------------------	---------------

The plot for Type M triple-separated thorium is shown in Figure 7-3. Other than the fact that there is faster clearance of the thorium from the chest, all of the discussion above is directly applicable to Type M material.



Figure 7-3. Lead-212 chest burden after an acute inhalation intake of Type M thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1.

7.1.2 Adjustment of Thorium Intakes

As shown in the plots above, for a given <u>thorium intake</u>, the approximate method will <u>overestimate</u> the ²¹²Pb chest burden for a length of time after the intake (~1 year for Type S material). Therefore, for a given ²¹²Pb chest burden, the approximate method will <u>underestimate</u> the thorium intake for the same length of time. In Figures 7-4 and 7-5, an adjustment factor of 1/1.1 is applied to the approximate ²¹²Pb chest burdens to ensure that they do not overestimate the exact ²¹²Pb chest burdens at times greater than 30 days after intake.



Figure 7-4. Lead-212 chest burden after an acute inhalation intake of Type S thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1 with vertical dashed line at t = 30 days after intake.



Type M thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1 with vertical dashed line at t = 30 days after intake.

When using the approximate method to calculate thorium intakes from ²¹²Pb chest burdens, the intake calculated with IMBA is multiplied by an adjustment factor of 1.1 to achieve the desired end of not underestimating the intake that would have been calculated using the exact method.

7.1.3 Guidance for Acute Intakes

Based on the discussion above, the following guidance is offered on how to use the approximate method to evaluate ²¹²Pb chest count data after acute inhalation intakes of Type M or S triple-separated thorium:

Assume a single measured ²¹²Pb chest burden. Evaluate the chest burden with a ²²⁸Th biokinetic model in IMBA. Multiply the calculated ²²⁸Th intake by a factor of 1.1 and assign it as the intake of ²²⁸Th. Divide this estimated ²²⁸Th intake by the ²²⁸Th:²³²Th ratio of 0.19:1 to obtain the ²³²Th intake. For ²¹²Pb chest burdens that are measured more than 30 days after an acute intake, these approximate intakes will not underestimate the intakes that would be calculated with exact methods.

7.2 CHRONIC INTAKES

The plot in Figure 7-6 shows the ²¹²Pb chest burden as a function of time after a chronic intake of 1 nCi/d of ²³²Th and 0.19 nCi/d of ²²⁸Th (both being 5- μ m AMAD Type S material). In other words, the time on the abscissa is the length of the time after the start of the chronic intake and the time that the chest burden is determined. The two curves cross at ~700 days.



The equations for chronic intakes are essentially the same as in the case of acute intakes except that the functions have an argument for the length of the constant chronic intake period. The exact chest burden q of ²¹²Pb at t days after the start of a chronic inhalation intake lasting t_c days is given by:

$$q(t,t_{c}) = q_{\text{pbth}232}(t,t_{c}) + q_{\text{pbth}228}(t,t_{c}) \qquad t \ge t_{c}$$
(7-14)

The relationship expressed in terms of intakes and IRFs is:

$$q(t,t_c) = I_{\text{th}232}\tilde{m}_{\text{pbth}232}(t,t_c) + I_{\text{th}228}\tilde{m}_{\text{pbth}228}(t,t_c) \qquad t \ge t_c$$

$$(7-15)$$

Applying the two approximations from Section 7.1 gives the following approximation to q:

$$q'(t,t_c) = I_{\text{th228}}\tilde{m}_{\text{th228}}(t,t_c)$$
(7-16)

Example 7-3

For example, assume that a ²¹²Pb chest burden of 1.5 nCi is observed at the end of a 365-day chronic inhalation intake of Type S triple-separated thorium. Given a ²²⁸Th:²³²Th ratio of 0.19:1, the total intake of ²³²Th is:

$$I_{\text{th}232} = \frac{1.5 \,\text{nCi}}{\tilde{m}_{\text{pbth}232} \left(365, 365\right) + 0.19 \tilde{m}_{\text{pbth}228} \left(365, 365\right)}$$
$$= \frac{1.5 \,\text{nCi}}{1.641 \text{E-04} + (0.19) \left(0.02654\right)}$$
$$= 288.1 \,\text{nCi}$$
(7-17)

which translates into $0.19 \times 288.1 \text{ nCi} = 54.74 \text{ nCi}$ of ²²⁸Th. This can be seen by rearranging the above equation:

$$1.5 nCi = (288.1 nCi)(1.641E-04) + (54.74 nCi)(0.02654)$$
(7-18)

Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 32 of 73

The intake rates are obtained by dividing the intakes by $t_c = 365$ days. With the approximate method the intake of ²²⁸Th is:

$$I_{\text{th228}} = \frac{1.5\,\text{nCi}}{\tilde{m}_{\text{th228}}\left(365,365\right)} = \frac{1.5\,\text{nCi}}{\left(0.02980\right)} = 50.34\,\text{nCi}$$
(7-19)

which translates into 50.34 nCi \div 0.19 = 264.9 nCi of ²³²Th.

The plot for Type M triple-separated thorium is shown in Figure 7-7. After a few hundred days the 212 Pb chest burden achieves a steady state condition with the approximate method giving a chest burden ~10% higher than the exact method.



Figure 7-7. Lead-212 chest burden after a chronic inhalation intake of Type M thorium having a 228 Th to 232 Th ratio of 0.19:1.

7.2.1 Adjustment of Chronic Thorium Intakes

In Figures 7-8 to 7-13, the ²¹²Pb chest burdens at various times during and after 365 day, 1,000 day, and 5,000-day constant chronic intakes are presented. As with the acute intakes, the approximate ²¹²Pb chest burdens are adjusted by a factor of 1/1.1. This illustrates that intake rates that are calculated from ²¹²Pb chest counts with the approximate method can be adjusted by a factor of 1.1 to ensure that the intake rates do not underestimate the intake rates that are calculated with the exact method.



Figure 7-8. Lead-212 chest burden during and after a 365-day chronic inhalation intake of Type S thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1. The vertical dashed line is at t = 365 days.



Figure 7-9. Lead-212 chest burden during and after a 1,000-day chronic inhalation intake of Type S thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1. The vertical dashed line is at t = 1,000 days.







Figure 7-11. Lead-212 chest burden during and after a 365-day chronic inhalation intake of Type M thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1. The vertical dashed line is at t = 365 days.







Figure 7-13. Lead-212 chest burden during and after a 5,000-day chronic inhalation intake of Type M thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1. The vertical dashed line is at t = 5,000 days.

7.2.2 Guidance for Chronic Intakes

Based on the discussion above, the following guidance is offered on how to use the approximate method to evaluate ²¹²Pb chest count data after constant chronic inhalation intakes of triple-separated thorium:

Assume a single measured ²¹²Pb chest burden. Evaluate the chest burden with a ²²⁸Th biokinetic model in IMBA. Multiply the calculated ²²⁸Th intake rate by a factor of 1.1 and assign it as the intake rate of $\frac{228}{\text{Th}}$. Divide this estimated ²²⁸Th intake rate by the ²²⁸Th:²³²Th ratio of 0.19:1 to obtain the ²³²Th intake rate. For chronic intakes longer than 1 year these approximate intakes will not underestimate the intakes that would be calculated with exact methods.

	Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 36 of 73
--	------------------------------	-----------------	----------------------------	---------------

8.0 USING IMBA FOR WHOLE-BODY COUNTS

8.1 ACUTE INTAKES

Assume a mixture of 1 nCi of ²³²Th and 1 nCi of ²²⁸Th (both being 5-µm AMAD Type S material) was inhaled. The ²¹²Pb whole-body burden as a function of time after the acute intake is shown in Figure 8-1.



of Type S thorium having a ²²⁸Th to ²³²Th ratio of 1:1.

Analogous to the chest counts, the exact body burden q of ²¹²Pb at t days after an acute inhalation intake is given by:

$$q(t) = q_{\text{pbth232}}(t) + q_{\text{pbth228}}(t)$$
(8-1)

where $q_{pbth232}$ is the whole-body burden of ²¹²Pb that grows in from the inhaled ²³²Th and $q_{pbth228}$ is the whole-body burden of ²¹²Pb that grows in from the inhaled ²²⁸Th. The relationship expressed in terms of intakes and IRFs is:

$$q(t) = I_{\text{th}232} m_{\text{pbth}232}(t) + I_{\text{th}228} m_{\text{pbth}228}(t)$$
(8-2)

Applying the two approximations from Section 7.1 gives the following approximation to q:

$$q'(t) = I_{\text{th228}} m_{\text{th228}}(t)$$
 (8-3)

As seen in the plot above, these approximations provide reasonably accurate estimates of the ²¹²Pb burden between approximately 10 and 1,000 days after the intake.
Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 37 of 73

Example 8-1

For example, assume that a ²¹²Pb whole-body burden of 1.5 nCi is observed at 100 days after an acute inhalation intake of this Type S thorium. Given a ²²⁸Th:²³²Th ratio of 1:1, the intake of ²³²Th is:

$$I_{\text{th}232} = \frac{1.5 \,\text{nCi}}{m_{\text{pbth}232} (100) + m_{\text{pbth}228} (100)}$$
$$= \frac{1.5 \,\text{nCi}}{(4.750 \text{E}-05) + (3.130 \text{E}-02)}$$
$$= 4.785 \text{E}+01 \text{nCi}$$
(8-4)

which translates into 47.85 nCi of ²²⁸Th. These intakes can be checked by calculating the expected ²¹²Pb whole-body burden and seeing if it equals the burden from which the intakes were calculated:

$$1.5 \text{ nCi} = (4.785\text{E}+01\text{nCi}) \left[(4.750\text{E}-05) + (3.130\text{E}-02) \right]$$
(8-5)

With the approximate method we have a ²²⁸Th intake of:

$$I_{\text{th228}} = \frac{1.5 \,\text{nCi}}{m_{\text{th228}} \left(100\right)} = \frac{1.5 \,\text{nCi}}{3.420 \text{E-}02} = 4.386 \text{E+}1 \text{nCi}$$
(8-6)

which translates into a 43.86 nCi intake of ²³²Th.

The plot in Figure 8-1 can be interpreted to mean that the approximate method will underestimate intakes at times before ~500 days after the intake (where the curves cross) and overestimate intakes after that day.

8.1.1 <u>Triple-Separated Thorium Mixture</u>

As noted in Section 3.0, triple-separated thorium has a 228 Th: 232 Th ratio of 0.19:1. Assume a mixture of 1 nCi of 232 Th and 0.19 nCi of 228 Th (both being 5-µm AMAD Type S material) was inhaled. The 212 Pb whole-body burden as a function of time after the acute intake is shown in Figure 8-2.



Figure 8-2. Lead-212 whole-body burden after an acute inhalation intake of Type S thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1.

Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 38 of 73

As shown above, the ²¹²Pb body burden expressed in terms of intakes and IRFs is:

$$q(t) = I_{\text{th}232} m_{\text{pbth}232}(t) + I_{\text{th}228} m_{\text{pbth}228}(t)$$
(8-7)

Applying the two approximations from Section 7.1 gives the following approximation to q:

$$q'(t) = I_{\text{th}228} m_{\text{th}228}(t)$$
 (8-8)

Example 8-2

For example, assume that a ²¹²Pb whole-body burden of 1.5 nCi is observed at 100 days after an acute inhalation intake of this Type S thorium. Given a ²²⁸Th:²³²Th ratio of 0.19:1, the intake of ²³²Th is:

$$I_{\text{th}232} = \frac{1.5 \text{nCi}}{m_{\text{pbth}232} (100) + 0.19 m_{\text{pbth}228} (100)}$$
$$= \frac{1.5 \text{nCi}}{(4.130\text{E}-05) + (0.19) (3.900\text{E}-02)}$$
$$= 2.013\text{E}+02 \text{nCi}$$
(8-9)

which translates into 0.19 \times 201.3 nCi = 38.25 nCi of ²²⁸Th. As a conceptual check, it is useful to show that:

$$1.5nCi = (201.3nCi)(4.130E-05) + (38.25)(3.900E-02)$$
(8-10)

With the approximate method the intake of ²²⁸Th is:

$$I_{\text{th228}} = \frac{1.5\,\text{nCi}}{m_{\text{th228}}\,(100)} = \frac{1.5\,\text{nCi}}{3.420\text{E-}02} = 4.386\text{E+}01\text{nCi}$$
(8-11)

which translates into 43.86 nCi \div 0.19 = 230.8 nCi of ²³²Th.

The plot for Type M triple-separated thorium is shown in Figure 8-3. Other than the fact that there is faster clearance of the thorium from the chest, all of the discussion above is directly applicable to Type M material.





8.1.2 Adjustment of Thorium Intakes

As shown in Figures 8-1 to 8-3, for a given <u>thorium intake</u>, the approximate method will <u>overestimate</u> the ²¹²Pb whole-body burden for a length of time after the intake (~2 years for Type S material). Therefore, for a given ²¹²Pb whole-body <u>burden</u>, the approximate method will <u>underestimate</u> the thorium intake for the same length of time. In Figures 8-4 and 8-5, an adjustment factors of 1/1.2 (Type S) and 1/1.5 (Type M) are applied to the approximate ²¹²Pb whole-body burdens to ensure that they do not overestimate the exact ²¹²Pb whole-body burdens at times greater than 30 days after intake.



Figure 8-4. Lead-212 whole-body burden after an acute inhalation intake of Type S thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1 with vertical dashed line at t = 30 days after intake.



Figure 8-5. Lead-212 whole-body burden after an acute inhalation intake of Type M thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1 with vertical dashed line at t = 30 days after intake.

When using the approximate method to calculate thorium intakes from ²¹²Pb whole-body burdens, the intake is multiplied by the appropriate adjustment factor to achieve the desired end of not underestimating the intake that would have been calculated using the exact method.

8.1.3 Guidance for Acute Intakes

Based on the discussion above, the following guidance is offered on how to use the approximate method to evaluate ²¹²Pb whole-body count data after acute inhalation intakes of Type M or S thorium:

Assume a single measured ²¹²Pb whole-body burden. Evaluate the whole-body burden with a Type M ²²⁸Th biokinetic model in IMBA. Multiply the calculated ²²⁸Th intake by a factor of 1.5 and assign it as the intake of ²²⁸Th. Divide this estimated ²²⁸Th intake by the ²²⁸Th.²³²Th ratio of 0.19:1 to obtain the ²³²Th intake. For ²¹²Pb whole-body burdens that were measured more than 30 days after an acute intake, these approximate intakes will not underestimate the Type M intakes that would be calculated with exact methods. For Type S thorium use a factor of 1.2 instead of 1.5.

8.2 CHRONIC INTAKES

The plot in Figure 8-6 shows the ²¹²Pb whole-body burden as a function of time after a chronic intake of 1 nCi/d of ²³²Th and 0.19 nCi/d of ²²⁸Th (both being 5- μ m AMAD Type S material). In other words, the time on the abscissa is the length of the time after the start of the chronic intake and the time that the whole-body burden is determined.





The equations for chronic intakes are essentially the same as in the case of acute intakes except that the functions have an argument for the length of the constant chronic intake period. The exact whole-body burden q of ²¹²Pb at t days after the start of a chronic inhalation intake over t_c days is given by:

$$q(t,t_{c}) = q_{\text{pbth232}}(t,t_{c}) + 0.19q_{\text{pbth228}}(t,t_{c}) \qquad t \ge t_{c}$$
(8-12)

Applying the two approximations from Section 7.1 gives the following approximation to q:

$$q'(t,t_c) = q_{\text{th228}}(t,t_c) \tag{8-13}$$

Example 8-3

For example, assume that a ²¹²Pb whole-body burden of 1.5 nCi is observed at the end of a 365-day chronic inhalation intake of Type S triple-separated thorium. The exact total intake of ²³²Th is:

$$I_{\text{th}232} = \frac{1.5 \,\text{nCi}}{\tilde{m}_{\text{pbth}232} \left(365, 365\right) + 0.19 \tilde{m}_{\text{pbth}228} \left(365, 365\right)}$$
$$= \frac{1.5 \,\text{nCi}}{\left(1.681 \text{E-04}\right) + \left(0.19\right) \left(2.767 \text{E-02}\right)}$$
$$= 2.765 \text{E+02nCi}$$
(8-14)

which translates into 0.19 x 276.7 nCi = 52.53 nCi of 228 Th. This can be seen by rearranging the above equation:

$$1.5 nCi = (276.7 nCi)(1.681E-04) + (52.53 nCi)(2.767E-02)$$
(8-15)

The intake rates are obtained by dividing the intakes by $t_c = 365$ days. With the approximate method the intake of ²²⁸Th is:

$$I_{\text{th228}} = \frac{1.5 \,\text{nCi}}{\tilde{m}_{\text{th228}} \left(365, 365\right)} = \frac{1.5 \,\text{nCi}}{\left(3.378 \text{E-02}\right)} = 4.440 \text{E+01nCi}$$
(8-16)

Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 42 of 73

which gives 44.40 nCi \div 0.19 = 233.7 nCi of ²³²Th. The plot for Type M triple-separated thorium is shown in Figure 8-7.



Figure 8-7. Lead-212 whole-body burden after a chronic inhalation intake of Type M thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1.

8.2.1 Adjustment of Chronic Thorium Intakes

In Figures 8-8 to 8-13, the ²¹²Pb whole-body burdens at various times during and after 365-, 1,000-, and 5,000-day constant chronic intakes are presented. As with the acute intakes, the approximate ²¹²Pb whole-body burdens are adjusted by a factor of 1/1.2 for Type S and 1/1.5 for Type M. This illustrates that intake rates that are calculated from ²¹²Pb whole-body counts with the approximate method can be adjusted by the appropriate factor to ensure that the intake rates do not underestimate the intake rates that would be calculated with the exact method.



Figure 8-8. Lead-212 whole-body burden during and after a 365-day chronic inhalation intake of Type S thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1. The vertical dashed line is at t = 365 days.







Figure 8-10. Lead-212 whole-body burden during and after a 5,000-day chronic inhalation intake of Type S thorium having a 228 Th to 232 Th ratio of 0.19:1. The vertical dashed line is at *t* = 5,000 days.

8.2.2 Guidance for Chronic Intakes

Based on the discussion above, the following guidance is offered on how to use the approximate method to evaluate ²¹²Pb whole-body count data after constant chronic inhalation intakes of triple-separated thorium:

Assume a single measured ²¹²Pb whole-body burden. Evaluate the whole-body burden with a Type M ²²⁸Th biokinetic model in IMBA. Multiply the calculated ²²⁸Th intake rate by a factor of 1.5 and assign it as the intake rate of ²²⁸Th. Divide this estimated ²²⁸Th intake rate by the ²²⁸Th.²³²Th ratio of 0.19:1 to obtain the ²³²Th intake rate. For chronic intakes longer than 1 year these approximate intakes will not underestimate the Type M intakes that would be calculated with exact methods. For Type S thorium use a factor of 1.2 instead of 1.5.



Figure 8-11. Lead-212 whole-body burden during and after a 365-day chronic inhalation intake of Type M thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1. The vertical dashed line is at t = 365 days.



Figure 8-12. Lead-212 whole-body burden during and after a 1,000-day chronic inhalation intake of Type M thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1. The vertical dashed line is at t = 1,000 days.





9.0 USING IMBA FOR TOTAL THORIUM IN URINE

This section discusses methods for adjustment of intakes and intake rates of 232 Th and 228 Th that are calculated with IMBA from total thorium (232 Th + 228 Th) measurements of urine samples so that the intakes and intake rates will not underestimate those that would be calculated with exact methods (i.e., using DCAL). These adjustments can be used when an overestimate of dose is appropriate. Best estimates of dose require the use of DCAL.

9.1 ACUTE INTAKES

Assume a mixture of 1 nCi of ²³²Th and 1 nCi of ²²⁸Th (both being 5-µm AMAD Type S material) was inhaled. The total thorium (henceforth referred to simply as "thorium") in 24-hour incremental urine samples as a function of time after the acute intake is shown in Figure 9-1.



inhalation intake of Type S thorium having a ²²⁸Th to ²³²Th ratio of 1:1.

|--|

The exact content q of thorium in the urine at t days after an acute inhalation intake is given by:

$$q(t) = q_{\text{th}232}(t) + q_{\text{th}1232}(t) + q_{\text{th}228}(t)$$
(9-1)

where q_{th232} is the amount of ²³²Th in the sample, $q_{thth232}$ is the amount of ²²⁸Th in the sample that grows in from the inhaled ²³²Th, and q_{th228} is the amount of ²²⁸Th in the sample from the inhaled ²²⁸Th. These exact contents are calculated with DCAL, which accounts for independent kinetics of the thorium decay chain. The red excretion curve in Figure 9-1 was calculated using the exact method. An approximation that can be made here is that there is negligible ingrowth of ²²⁸Th from the ²³²Th component of the intake. That is:

$$q_{\text{thth}_{232}}(t) = 0$$
 {Approximation A} (9-2)

This gives the following approximation to *q*:

$$q'(t) = q_{\text{th}232}(t) + q_{\text{th}228}(t)$$
 (9-3)

where q_{th232} is the ²³²Th urine content and q_{th228} is the ²²⁸Th urine contents at time *t*, both of which can be calculated with IMBA. The blue excretion curve in Figure 9-1 was calculated using the approximate method. As seen in Figure 9-1, this approximation provides reasonably accurate estimates of the thorium urine content for a couple of years after the intake. At later times the approximate method underestimates the urinary excretion rate.

Example 9-1

For example, assume that 0.0015 nCi of thorium is observed in a 24-hour urine sample completed at 100 days after an acute inhalation intake of this Type S thorium. Given a ²²⁸Th:²³²Th ratio of 1:1, the intake of ²³²Th is:

$$I_{\text{th}232} = \frac{0.0015 \text{nCi}}{m_{\text{th}232} (100) + m_{\text{th}1232} (100) + m_{\text{th}228} (100)}$$
$$= \frac{0.0015 \text{nCi}}{3.65\text{E}-07 + 4.64\text{E}-10 + 3.31\text{E}-07}$$
$$= 2,154 \text{nCi}$$
(9-4)

which translates into 2,154 nCi of ²²⁸Th. These intakes can be checked by calculating the expected thorium urine content and determining if it equals the content from which the intakes were calculated:

$$0.0015 \,\mathrm{nCi} = I_{\mathrm{th232}} m_{\mathrm{th232}} \left(100\right) + I_{\mathrm{th232}} m_{\mathrm{thth232}} \left(100\right) + I_{\mathrm{th228}} m_{\mathrm{th228}} \left(100\right) \tag{9-5}$$

$$0.0015nCi = (2,154nCi)(3.65E-07) + (2,154nCi)(4.64E-10) + (2,154nCi)(3.31E-07)$$
(9-6)

With the approximate method we have a ²³²Th intake of:

$$I_{\text{th}232} = \frac{0.0015 \text{nCi}}{m_{\text{th}232} (100) + m_{\text{th}228} (100)}$$
$$= \frac{0.0015 \text{nCi}}{3.65\text{E}-07 + 3.31\text{E}-07}$$
$$= 2.155 \text{nCi}$$
(9-7)

which translates into a 2,155 nCi intake of ²²⁸Th. From the equations above it should be evident that, for a given quantity of thorium in the urine, the approximate method will always give an intake that is greater than or equal to the intake from the exact method (this is reflected in Figure 9-1). Further, this is true regardless of the ²²⁸Th.²³²Th ratio, dissolution type (M or S), or exposure pattern (acute or chronic).

9.1.1 <u>Triple-Separated Thorium Mixture</u>

As noted in Section 3.0, triple-separated thorium has a 228 Th: 232 Th ratio of 0.19:1. Assume a mixture of 1 nCi of 232 Th and 0.19 nCi of 228 Th (both being 5-µm AMAD Type S material) was inhaled. The thorium urine content as a function of time after the acute intake is shown in Figure 9-2.



Figure 9-2. Thorium urine content after an acute inhalation intake of Type S thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1.

Example 9-2

For example, assume that 0.0015 nCi of thorium is observed in a 24-hour urine sample completed at 100 days after an acute inhalation intake of this Type S thorium. Given a ²²⁸Th:²³²Th ratio of 0.19:1, the intake of ²³²Th is:

$$I_{\text{th}232} = \frac{0.0015 \text{nCi}}{m_{\text{th}232} (100) + m_{\text{th}1232} (100) + 0.19 m_{\text{th}228} (100)}$$
$$= \frac{0.0015 \text{nCi}}{3.65\text{E}-07 + 4.64\text{E}-10 + (0.19)(3.31\text{E}-07)}$$
$$= 3,502 \text{nCi}$$
(9-8)

which translates into 665 nCi of ²²⁸Th. These intakes can be checked by calculating the expected thorium urine content and seeing if it equals the content from which the intakes were calculated:

$$0.0015 nCi = (3,502 nCi)(3.65E-07) + (3,502 nCi)(4.64E-10) + (0.19)(3,502 nCi)(3.31E-07)$$
(9-9)

With the approximate method we have a ²³²Th intake of:

$$I_{\text{th}232} = \frac{0.0015 \text{nCi}}{m_{\text{th}232} (100) + 0.19 m_{\text{th}228} (100)}$$
$$= \frac{0.0015 \text{nCi}}{3.65\text{E}-07 + (0.19)(3.31\text{E}-07)}$$
$$= 3,506 \text{nCi}$$
(9-10)

which translates into a 666 nCi intake of ²²⁸Th.

9.1.2 <u>An Additional Approximation</u>

The approximation above will provide an estimate of the intake that will not be less than the intake that would be calculated with the exact method regardless of the dissolution type or exposure pattern. However, in practice this approximation is cumbersome to use in IMBA because it requires calculation of intakes of two different radionuclides (²³²Th and ²²⁸Th), a task that requires two computational runs. An additional simplifying approximation that can be used with triple-separated thorium is to use the ²³²Th urinary excretion function in place of the ²²⁸Th function:

$$q_{\text{th228}}(t) = q_{\text{th232}}(t)$$
 {Approximation B} (9-11)

which gives:

$$q''(t) = q_{\text{th}232}(t) + 0.19q_{\text{th}232}(t)$$
(9-12)

Document No. ORAUT-OTIB-0076 Revis	sion No. 00 Effective I	Date: 07/10/2014	Page 49 of 73
------------------------------------	---------------------------	------------------	---------------

This approximation is shown in Figure 9-3 as the gold curve, which partially obscures the exact (red) curve. Applying Approximations A and B gives a ²³²Th intake of:

$$I_{\text{th}232} = \frac{0.0015\,\text{nCi}}{m_{\text{th}232}\,(100) + 0.19\,m_{\text{th}232}\,(100)} = \frac{0.0015\,\text{nCi}}{1.19\,m_{\text{th}232}\,(100)} \tag{9-13}$$

$$I_{th232} = \frac{0.0015 \,\text{nCi}}{3.65\text{E}-07 + (0.19)(3.65\text{E}-07)} = \frac{0.0015 \,\text{nCi}}{(1.19)(3.65\text{E}-07)} = 3,453 \,\text{nCi}$$
(9-14)

which translates into a 656-nCi intake of ²²⁸Th. These approximations provide intake estimates for Type S material that are within \pm 5% of the exact intake for the periods studied here (i.e., less than 4,000 days).

As shown in Figure 9-4, there is a maximum nonconservative discrepancy on the order of 12% when Approximations A and B are applied to Type M thorium. To adjust for these underestimates, ²³²Th intakes that are calculated with Approximations A and B are multiplied by a factor of 1.15. However, the ratio of 1.15:1.19 can be rounded up to 1, a conservative approximation that allows us to simplify the guidance even further:

$$\left(\frac{1.15}{1.19}\right)I_{\text{th}232} = I_{\text{th}232}$$
 {Approximation C} (9-15)

9.1.3 Guidance for Acute Intakes

Based on the discussion above, the following guidance could be offered on how to use the approximate method to evaluate thorium urine bioassay measurements after acute inhalation intakes of Type M or S thorium:

Assume a single measured thorium urine bioassay result. Evaluate the result with a ²³²Th biokinetic model in IMBA to obtain an estimate of the ²³²Th intake. Multiply this estimate of the ²³²Th intake by the ²²⁸Th:²³²Th ratio of 0.19:1 to obtain the estimate of the ²²⁸Th intake. These approximate intakes will not underestimate the intakes that would be calculated with exact methods.



Figure 9-3. Thorium urine content after an acute inhalation intake of Type S thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1 showing excretion with Approximation A (blue line) and with Approximations A and B (gold line).





9.2 CHRONIC INTAKES

The plot in Figure 9-5 shows the thorium content of a 24-hour incremental urine sample as a function of time after a chronic intake of 1 nCi/d of ²³²Th and 0.19 nCi/d of ²²⁸Th (both being 5- μ m AMAD Type S material). The time on the abscissa is the length of time after the start of the chronic intake that the urine sample was completed. The actual length of the chronic intake is 1 day less than the day the urine sample was completed (i.e., urine samples are not collected while the individual is being exposed).



Figure 9-5. Thorium urine content after a chronic inhalation intake of Type S thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1.

The equations for chronic intakes are essentially the same as in the case of acute intakes except that the functions have an argument for the length of the constant chronic intake period. The exact thorium content q of a 24-hour urine sample completed at t days after the start of a chronic inhalation intake over t_c days is given by:

$$q(t,t_{c}) = q_{\text{th232}}(t,t_{c}) + q_{\text{thth232}}(t,t_{c}) + q_{\text{th228}}(t,t_{c}) \qquad \{t \ge t_{c} + 1\}$$
(9-16)

Applying Approximation A gives the following:

$$q(t,t_{c}) = q_{\text{th232}}(t,t_{c}) + q_{\text{th228}}(t,t_{c}) \qquad \{t \ge t_{c} + 1\}$$
(9-17)

In terms of intakes and IRFs:

$$q(t,t_{c}) = I_{\text{th}_{232}}\tilde{m}_{\text{th}_{232}}(t,t_{c}) + I_{\text{th}_{232}}\tilde{m}_{\text{th}_{132}}(t,t_{c}) + I_{\text{th}_{228}}\tilde{m}_{\text{th}_{228}}(t,t_{c}) \qquad \{t \ge t_{c} + 1\}$$
(9-18)

and:

$$q(t,t_{c}) = I_{th232}\tilde{m}_{th232}(t,t_{c}) + I_{th228}\tilde{m}_{th228}(t,t_{c}) \qquad \{t \ge t_{c}+1\}$$
(9-19)

Example 9-3

For example, assume that 0.0015 nCi of thorium is observed in a 24-hour urine sample completed on day 366 after a 365-day chronic inhalation intake of Type S triple-separated thorium. Given a ²²⁸Th: ²³²Th intake ratio of 0.19:1, the total intake of ²³²Th is:

$$I_{\text{th}232} = \frac{0.0015 \text{nCi}}{\tilde{m}_{\text{th}232} \left(366, 365\right) + \tilde{m}_{\text{th}1232} \left(366, 365\right) + 0.19 \tilde{m}_{\text{th}228} \left(366, 365\right)}$$
$$= \frac{0.0015 \text{nCi}}{4.006\text{E}-07 + 1.657\text{E}-09 + (0.19)(3.500\text{E}-07)}$$
(9-20)
$$= 3,200 \text{nCi}$$

Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 52 of 73

which translates into 0.19 × 3,200 nCi = 608 nCi of 228 Th. This can be verified as accomplished before by using the intakes to calculate the 228 Th content of the urine sample:

$$0.0015 \text{ nCi} = (3,200 \text{ nCi})(4.006\text{E}-07) + (3200 \text{ nCi})(1.657\text{E}-09) + (608 \text{ nCi})(3.500\text{E}-07)$$
 (9-21)

The intake rates are obtained by dividing the intakes by $t_c = 365$ days. With the application of Approximation A the intake of ²³²Th is:

$$I_{\text{th}232} = \frac{0.0015 \,\text{nCi}}{\tilde{m}_{\text{th}232} \left(366, 365\right) + 0.19 \tilde{m}_{\text{th}228} \left(366, 365\right)}$$
$$= \frac{0.0015 \,\text{nCi}}{4.006\text{E-07} + \left(0.19\right) \left(3.500\text{E-07}\right)}$$
$$= 3,212 \,\text{nCi}$$
(9-22)

which translates into a 610 nCi intake of ²²⁸Th.

Figures 9-6 to 9-9 show the thorium urinary excretion curves for chronic intakes of Type M and S triple-separated thorium. The 15% intake adjustment applied in the acute intake case above is adequate to make chronic intake rates that are estimated with Approximations A and B not underestimate the intake rates that would be calculated with the exact method. For example, the ²³²Th intake that was calculated with Approximations A, B, and C is:

$$I_{\text{th}232} = \frac{0.0015\,\text{nCi}}{\tilde{m}_{\text{th}232}\,(365,365)} = \frac{0.0015\,\text{nCi}}{4.006\text{E-07}} = 3,745\,\text{nCi}$$
(9-23)

The ²²⁸Th intake is 712 nCi.



Figure 9-6. Thorium urine content after a 365-day chronic inhalation intake of Type S thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1. The blue line is the excretion with Approximation A and the gold line is the excretion with Approximations A and B.



Figure 9-7. Thorium urine content after a 1,000-day chronic inhalation intake of Type S thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1. The blue line is the excretion with Approximation A and the gold line is the excretion with Approximations A and B.

9.2.1 <u>Guidance for Chronic Intakes</u>

Based on the discussion above, the following guidance is offered on how to use the approximate method to evaluate thorium urine bioassay measurements after constant chronic inhalation intakes of Type M or S thorium:

Assume a single measured thorium urine bioassay result. Evaluate the result with a ²³²Th biokinetic model in IMBA to obtain an estimate of the ²³²Th intake rate. Multiply this estimate of the ²³²Th intake rate by the ²²⁸Th.²³²Th ratio of 0.19:1 to obtain the estimate of the ²²⁸Th intake rate. These approximate intake rates will not underestimate the intake rates that would be calculated with exact methods.



Figure 9-8. Thorium urine content after a 365-day chronic inhalation intake of Type M thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1. The blue line is the excretion with Approximation A and the gold line is the excretion with Approximations A and B.



intake of Type M thorium having a ²²⁸Th to ²³²Th ratio of 0.19:1. The blue line is the excretion with Approximation A and the gold line is the excretion with Approximations A and B.

10.0 USING IMBA FOR THORIUM-228 IN URINE

This section discusses adjustments to intakes and intake rates of ²³²Th and ²²⁸Th that are calculated with IMBA from ²²⁸Th that is measured in urine samples so that the intakes and intake rates will not underestimate those that would be calculated with exact methods (DCAL). These adjustments may be used when an overestimate of dose is appropriate. Best estimates of dose require the use of DCAL.

10.1 ACUTE INTAKES

Assume a mixture of 1 nCi of ²³²Th and 1 nCi of ²²⁸Th (both being 5- μ m AMAD Type S material) was inhaled. The ²²⁸Th in 24-hour incremental urine samples as a function of time after the acute intake is shown in Figure 10-1.



Figure 10-1. Thorium-228 in 24-hour incremental urine samples after an acute inhalation intake of Type S thorium having a ²²⁸Th to ²³²Th ratio of 1:1.

DOCUMENTINO, ORAUT-OTID-0076 I REVISION NO. 00 I Effective Date	e: 07/10/2014	Page 55 of 73
---	---------------	---------------

The exact content q of ²²⁸Th in the urine at t days after an acute inhalation intake is given by:

$$q(t) = q_{\text{thth232}}(t) + q_{\text{th228}}(t)$$

= $I_{\text{th232}}m_{\text{thth232}}(t) + I_{\text{th228}}m_{\text{th228}}(t)$ (10-1)

where q_{thth232} is the amount of ²²⁸Th in the sample that grows in from the inhaled ²³²Th and q_{th228} is the amount of ²²⁸Th in the sample from the inhaled ²²⁸Th. These exact contents are calculated with DCAL, which accounts for independent kinetics of the thorium decay chain and the loss of ²²⁰Rn. The red excretion curve in Figure 10-1 was calculated using the exact method. An approximation that can be made here is that there is negligible ingrowth of ²²⁸Th from the ²³²Th component of the intake. That is:

$$q_{\text{thth}_{232}}\left(t\right) = 0 \tag{10-2}$$

This gives the following approximation to *q*:

$$q'(t) = q_{\text{th}228}(t)$$
 (10-3)

where q_{th228} is the ²²⁸Th urine content at time *t* (which can be calculated with IMBA). The blue excretion curve in Figure 10-1 was calculated using the approximate method. As seen in the plot above, this approximation provides reasonably accurate estimates of the ²²⁸Th urine content for a couple of years after the intake. At later times the approximate method underestimates the urinary excretion rate.

Example 10-1

For example, assume that 0.0015 nCi of ²²⁸Th is observed in a 24-hour urine sample completed at 100 days after an acute inhalation intake of this Type S thorium. Given a ²²⁸Th:²³²Th ratio of 1: 1, the intake of ²³²Th is:

$$I_{\text{th}232} = \frac{0.0015 \text{nCi}}{m_{\text{th}th232} (100) + m_{\text{th}228} (100)}$$
$$= \frac{0.0015 \text{nCi}}{4.64\text{E}-10 + 3.31\text{E}-07}$$
$$= 4,525 \text{nCi}$$
(10-4)

which translates into 4,525 nCi of ²²⁸Th. These intakes can be checked by calculating the expected ²²⁸Th urine content and determining if it equals the content from which the intakes were calculated:

$$0.0015 \,\mathrm{nCi} = (4,525 \,\mathrm{nCi})(4.64 \,\mathrm{E}{-}\,10) + (4,525 \,\mathrm{nCi})(3.31 \,\mathrm{E}{-}\,07)$$
 (10-5)

With the approximate method we have a ²²⁸Th intake of:

$$I_{\text{th228}} = \frac{0.0015 \,\text{nCi}}{m_{\text{th228}} (100)} = \frac{0.0015 \,\text{nCi}}{3.31 \text{E-07}} = 4,532 \,\text{nCi}$$
(10-6)

which translates into a 4,532-nCi intake of ²³²Th. From the equations given above it should be evident that, for a given quantity of ²²⁸Th in the urine, the approximate method will always give an intake that

Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 56 of 73

is greater than or equal to the intake from the exact method (this is reflected in Figure 10-1). Further, this is true regardless of the ²²⁸Th:²³²Th ratio, dissolution type (M or S), or exposure pattern (acute or chronic).

10.1.1 <u>Triple-Separated Thorium Mixture</u>

Assume a mixture of 1 nCi of ²³²Th and 0.19 nCi of ²²⁸Th (both being 5-µm AMAD Type S material) was inhaled. The ²²⁸Th urine content as a function of time after the acute intake is shown in Figure 10-2.



Type S thorium having a 228 Th to 232 Th ratio of 0.19:1.

The exact content q of ²²⁸Th in the urine at t days after an acute inhalation intake is given by:

$$q(t) = q_{\text{thth}_{232}}(t) + q_{\text{th}_{228}}(t)$$
 (10-7)

The approximation to *q* is:

$$q'(t) = q_{\text{th}228}(t)$$
 (10-8)

In terms of intakes and IRFs:

$$q(t) = I_{\text{th}232} m_{\text{th}1232}(t) + I_{\text{th}228} m_{\text{th}228}(t)$$
(10-9)

$$q'(t) = I_{\text{th}228} m_{\text{th}228}(t)$$
 (10-10)

	Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 57 of 73
--	------------------------------	-----------------	----------------------------	---------------

Example 10-2

For example, assume that 0.0015 nCi of ²²⁸Th is observed in a 24-hour urine sample completed at 100 days after an acute inhalation intake of this Type S thorium. Given a ²²⁸Th:²³²Th ratio of 0.19:1, the intake of ²³²Th is:

$$I_{\text{th}232} = \frac{0.0015 \text{nCi}}{m_{\text{th}th232} (100) + 0.19 m_{\text{th}228} (100)}$$
$$= \frac{0.0015 \text{nCi}}{4.64\text{E} \cdot 10 + (0.19) (3.31\text{E} \cdot 07)}$$
(10-11)
$$= 23,676 \text{nCi}$$

which translates into 4,499 nCi of ²²⁸Th. These intakes can be checked by calculating the expected ²²⁸Th urine content and determining if it equals the content from which the intakes were calculated:

$$0.0015 \text{ nCi} = (23,676 \text{ nCi})(4.64\text{E}-10) + (4,499 \text{ nCi})(3.31\text{E}-07)$$
 (10-12)

With the approximate method we have a ²²⁸Th intake of:

$$I_{\text{th228}} = \frac{0.0015\,\text{nCi}}{m_{\text{th228}}\,(100)} = \frac{0.0015\,\text{nCi}}{3.31\text{E-07}} = 4,532\,\text{nCi}$$
(10-13)

which translates into 4,532 nCi \div 0.19 = 23,851 nCi of ²³²Th intake.

10.1.2 Guidance for Acute Intakes

Based on discussion given above, the following guidance is offered on how to use the approximate method to evaluate ²²⁸Th urine bioassay measurements after acute inhalation intakes of Type M or S thorium:

Assume a single measured ²²⁸Th urine bioassay result. Evaluate the result with a ²²⁸Th biokinetic model in IMBA and assign it as the intake of $\frac{^{228}Th}{^{228}Th}$. Divide this estimated ²²⁸Th intake by the ²²⁸Th:²³²Th ratio of 0.19:1 to obtain the $\frac{^{232}Th}{^{11}}$ intake. These approximate intakes will not underestimate the intakes that would be calculated with exact methods.

10.2 CHRONIC INTAKES

The plot in Figure 10-3 shows the ²²⁸Th content of a 24-hour incremental urine sample as a function of time after a chronic intake of 1 nCi/d of ²³²Th and 0.19 nCi/d of ²²⁸Th (both being 5-µm AMAD Type S material). The time on the abscissa is the length of time after the start of the chronic intake that the urine sample was completed. The actual length of the chronic intake is 1 day less than the day the urine sample was completed (i.e., urine samples are not collected while the individual is being exposed).





The equations for chronic intakes are essentially the same as in the case of acute intakes except that the functions have an argument for the length of the constant chronic intake period. The exact ²²⁸Th content *q* of a 24-hour urine sample completed at *t* days after the start of a chronic inhalation intake over t_c days is given by:

$$q(t,t_c) = q_{\text{thth}_{232}}(t,t_c) + q_{\text{th}_{228}}(t,t_c) \qquad \{t \ge t_c + 1\}$$
(10-14)

Applying the approximation gives the following:

$$q'\left(t,t_{c}\right) = q_{\text{th}228}\left(t,t_{c}\right) \tag{10-15}$$

In terms of intakes and IRFs:

$$q(t,t_{c}) = I_{\text{th}232}\tilde{m}_{\text{th}1232}(t,t_{c}) + I_{\text{th}228}\tilde{m}_{\text{th}228}(t,t_{c})$$
(10-16)

$$q'(t) = I_{\text{th228}} m_{\text{th228}}(t)$$
(10-17)

Example 10-3

For example, assume that 0.0015 nCi of ²²⁸Th is observed in a 24-hour urine sample completed on day 366 after a 365-day chronic inhalation intake of Type S triple-separated thorium. Given a ²²⁸Th:²³²Th ratio of 0.19:1, the total intake of ²³²Th is:

$$I_{\text{th}232} = \frac{0.0015 \,\text{nCi}}{\tilde{m}_{\text{th}1232} \left(366, 365\right) + 0.19 \tilde{m}_{\text{th}228} \left(366, 365\right)}$$
$$= \frac{0.0015 \,\text{nCi}}{1.657 \text{E} \cdot 09 + (0.19) \left(3.500 \text{E} \cdot 07\right)}$$
(10-18)
$$= 22,007 \,\text{nCi}$$

Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 59 of 73

which translates into 0.19 × 22,007 nCi = 4,181 nCi of 228 Th. This can be verified as accomplished before by using the intakes to calculate the 228 Th content of the urine sample:

$$0.0015 \text{nCi} = (22,007 \text{nCi})(1.657\text{E-09}) + (4,181 \text{nCi})(3.500\text{E-07})$$
(10-19)

The intake rates are obtained by dividing the intakes by $t_c = 365$ days. With the approximate method the intake of ²²⁸Th is:

$$I_{\text{th228}} = \frac{0.0015 \text{ nCi}}{\tilde{m}_{\text{th228}} (365, 365)}$$
$$= \frac{0.0015 \text{ nCi}}{(3.500\text{E-07})}$$
$$= 4,286 \text{ nCi}$$
(10-20)

which gives $4,286 \text{ nCi} \div 0.19 = 22,556 \text{ nCi} \text{ of } ^{232}\text{Th}$.

10.2.1 <u>Guidance for Chronic Intakes</u>

Based on discussion above, the following guidance is offered on how to use the approximate method to evaluate ²²⁸Th urine bioassay measurements after constant chronic inhalation intakes of Type M or S thorium:

Assume a single measured ²²⁸Th urine bioassay result. Evaluate the result with a ²²⁸Th biokinetic model in IMBA and assign it as the intake rate of $\frac{228}{\text{Th}}$. Divide this estimated ²²⁸Th intake rate by the ²²⁸Th:²³²Th ratio of 0.19:1 to obtain the $\frac{232}{\text{Th}}$ intake rate. These approximate intake rates will not underestimate the intake rates that would be calculated with exact methods.

11.0 ATTRIBUTIONS AND ANNOTATIONS

All information requiring identification was addressed via references integrated into the reference section of this document.

Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 60 of 73

REFERENCES

- ICRP (International Commission on Radiological Protection, 1979–1988, *Limits for Intakes of Radionuclides by Workers*, Publication 30, Parts 1–4 and Supplements, Pergamon Press, Oxford England. [SRDB Ref ID: 22733]
- ICRP (International Commission on Radiological Protection, 1995, *Dose Coefficients for Intakes of Radionuclides by Workers*, Publication 68, Pergamon Press, Oxford England. [SRDB Ref ID: 22731]

ATTACHMENT A STANDARD THORIUM MIXTURES

LIST OF TABLES

<u>TABLE</u>

<u>TITLE</u>

A-1	Ratios of ²²⁸ Th to ²³² Th activities for secular equilibrium and after one, two, and three chemical separations	. 65
A-2	Relative amounts of ²³² Th, ²²⁸ Ra, and ²²⁸ Th in single separated thorium as a function of time since separation	. 66

LIST OF FIGURES

FIGURES

<u>TITLE</u>

<u>PAGE</u>

A-1	Thorium- ²³² and ²²⁸ Th present as a function of time after separation of thorium from	
	other elements in the decay chain	62
A-2	Thorium-232, ²²⁸ Ra, and ²²⁴ Ra present after separation of thorium from other elements	
	in the decay chain	63
A-3	Thorium-232 and ²²⁸ Th present as a function of time after a second separation of	
	thorium from other elements in the decay chain	63
A-4	Thorium-232, ²²⁸ Ra, and ²²⁴ Ra present as a function of time after a second separation	
	of thorium from other elements in the decay chain	64
A-5	Thorium- ²³² and ²²⁸ Th present as a function of time after a third separation of thorium	
	from other elements in the decay chain	64
A-6	Thorium-232 ²²⁸ Ra, and ²²⁴ Ra present as a function of time after a third separation of	
	thorium from other elements in the decay chain	65
		00

ATTACHMENT A STANDARD THORIUM MIXTURES (continued)

To accurately evaluate a ²¹²Pb or ²²⁸Ac chest count in terms of an intake of thorium, the relative amounts of ²³²Th, ²²⁸Ra, and ²²⁸Th in the inhaled material have to be known. In certain cases a mixture of radionuclides can be specified that will provide a conservative estimate of the intake. These *standard thorium mixtures* are defined in this attachment.

Assume 1 Bq of ²³²Th in equilibrium with all of its progeny chemically stripped of everything except for the ²³²Th and ²²⁸Th. The time at which this occurs is referred to as t = 0 years. The activity of ²²⁸Th that is present in the source at various times after t = 0 years is shown in Figure A-1 (the activity of ²³²Th is constant at 1 Bq). The ²²⁸Th activity hits a minimum of 0.42 Bq at 4.55 years.



Figure A-1. Thorium-232 and ²²⁸Th present as a function of time after separation of thorium from other elements in the decay chain. At the time of separation all members of the decay chain were in equilibrium with the ²³²Th.

For all practical applications ²²⁴Ra, with a half-life of 3.66 days, is always in secular equilibrium with ²²⁸Th. However, ²²⁸Ra, with its half-life of 5.75 years is depleted and takes years to grow back to any significant degree. These progeny are important because ²¹²Pb (which can be measured in vivo) is in secular equilibrium with the ²²⁴Ra (which cannot be measured in vivo) and ²²⁸Ac (which can be measured in vivo) is in secular equilibrium with the ²²⁴Ra (which cannot be measured in vivo) and ²²⁸Ac (which can be measured in vivo) is in secular equilibrium with the ²²⁸Ra (which cannot be measured in vivo). The ingrowth curves for ²²⁴Ra and ²²⁸Ra are shown in Figure A-2. The minimum in the ²²⁴Ra curve coincides with the minimum in the ²²⁸Th curve.

If there is a second separation at 4.55 years after the first, the thorium will have the ²²⁸Th ingrowth curve shown in Figure A-3, which has a minimum of 0.26 Bq at 2.54 years after the second separation (or 2.54 + 4.55 = 7.09 years after the first separation).

The corresponding ²²⁴Ra and ²²⁸Ra curves after the second separation are shown in Figure A-4.

If there is a third separation at 7.09 years after the first, the thorium will have the ²²⁸Th ingrowth curve shown in Figure A-5, which has a minimum of 0.19 Bq at 1.75 years after the third separation (or 1.75 + 2.54 + 4.55 = 8.84 years after the first separation).

ATTACHMENT A STANDARD THORIUM MIXTURES (continued)

The corresponding ²²⁴Ra and ²²⁸Ra curves after the third separation are shown in Figure A-6.



Figure A-2. Thorium-232, ²²⁸Ra, and ²²⁴Ra present after separation of thorium from other elements in the decay chain. At the time of separation all members of the decay chain were in equilibrium with the ²³²Th.



Figure A-3. Thorium-232 and ²²⁸Th present as a function of time after a second separation of thorium from other elements in the decay chain. At the time of separation 4.55 years had elapsed since the first separation.

ATTACHMENT A STANDARD THORIUM MIXTURES (continued)



Figure A-4. Thorium-232, ²²⁸Ra, and ²²⁴Ra present as a function of time after a second separation of thorium from other elements in the decay chain. At the time of separation 4.55 years had elapsed since the first separation.



Figure A-5. Thorium-232 and ²²⁸Th present as a function of time after a third separation of thorium from other elements in the decay chain. At the time of separation 7.086 years had elapsed since the first separation.

ATTACHMENT A STANDARD THORIUM MIXTURES (continued)



Figure A-6. Thorium-232, ²²⁸Ra, and ²²⁴Ra present as a function of time after a third separation of thorium from other elements in the decay chain. At the time of separation 7.086 years had elapsed since the first separation.

These data are summarized in Table A-1. The ratio of ²²⁸Th activity to ²³²Th activity is shown for the cases of secular equilibrium (no chemical separation), a single chemical separation at t = 0 years, a second chemical separation at t = 4.550 years, and a third chemical separation at t = 7.086 years. Note that these chemical separations are timed to produce the greatest possible reduction of the ²²⁸Th/²³²Th ratio.

Time (yr)	No separations Th-228 (nCi/nCi ²³² Th)	One separation Th-228 (nCi/nCi ²³² Th)	Two separations Th-228 (nCi/nCi ²³² Th)	Three separations Th-228 (nCi/nCi ²³² Th)
0.000	1.000	1.0000	1.0000	1.0000
4.550	1.000	0.4221	0.4221	0.4221
7.086	1.000	0.4771	0.2633	0.2633
8.840	1.000	0.5446	0.3010	0.1905

Table A-1. Ratios of ²²⁸Th to ²³²Th activities for secular equilibrium and after one, two, and three chemical separations.

Therefore, the standard thorium mixtures are:

- Unseparated (equilibrium) thorium, which has a 1:1 ²²⁸Th to ²³²Th ratio;
- Single-separated thorium, which has a 0.42:1 ²²⁸Th to ²³²Th ratio;
- Double-separated thorium, which has a 0.26:1 ²²⁸Th to ²³²Th ratio; and
- Triple-separated thorium, which has a 0.19:1 ²²⁸Th to ²³²Th ratio.

ATTACHMENT A STANDARD THORIUM MIXTURES (continued)

Note that there is no ²²⁸Ra in these standard mixtures and that once a mixture is selected for a particular application it is assumed to be a constant and does not change as a function of time. For example, if triple-separated thorium is chosen for a facility during 1980 then the same mixture applies in 1995; that is, there is no ingrowth of ²²⁸Th during the 15 years.

The standard thorium mixtures give conservative ²²⁸Th to ²³²Th ratios that are independent of the age of the thorium. This means that to evaluate a ²¹²Pb chest count we have to specify the number of separations the material has gone through but not the time since separation (i.e., the age of the thorium). To evaluate an ²²⁸Ac chest count the age of the standard thorium mixture has to be specified because the quantity of parent ²²⁸Ra present is a strong function of the age of the thorium and an age that results in useful, conservative intake estimates cannot be specified. Relative quantities of ²³²Th, ²²⁸Ra, and ²²⁸Th present in single separated thorium (which is the most conservative mixture for evaluating ²²⁸Ac chest counts) as a function of time since separation are presented in Table A-2. In practice, one would specify the date that thorium separation activities ended at a given site and the minimum elapsed time between this date and the dates of the chest counts. The activity ratios for that elapsed time would be used to evaluate all ²²⁸Ac chest counts.

Years	Th-232	Ra228	Th228
0.5	1.000	0.058	0.839
1.0	1.000	0.114	0.715
2.0	1.000	0.214	0.548
3.0	1.000	0.303	0.461
4.0	1.000	0.383	0.426
5.0	1.000	0.453	0.425
6.0	1.000	0.515	0.443
7.0	1.000	0.570	0.474
8.0	1.000	0.619	0.511
9.0	1.000	0.662	0.551
10.0	1.000	0.700	0.591
11.0	1.000	0.734	0.630
12.0	1.000	0.765	0.667
13.0	1.000	0.791	0.701
14.0	1.000	0.815	0.732
15.0	1.000	0.836	0.761
16.0	1.000	0.855	0.787
17.0	1.000	0.871	0.810
18.0	1.000	0.886	0.831
19.0	1.000	0.899	0.850
20.0	1.000	0.910	0.867

Table A-2. Relative amounts of ²³²Th, ²²⁸ Ra, and ²²⁸Th in single separated thorium as a function of time since separation.

ATTACHMENT B OBTAINING CHRONIC INTAKE IRFs FROM ACUTE INTAKE IRFs

LIST OF FIGURES

FIGURES

TITLE

PAGE

B-1	Plot of whole-body retention versus time after an acute uptake of the hypothetical	
	radioactive material	68
B-2	Plot of whole-body retention versus time for a constant chronic uptake	70

Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 68 of 73
------------------------------	-----------------	----------------------------	---------------

ATTACHMENT B OBTAINING CHRONIC INTAKE IRFs FROM ACUTE INTAKE IRFs (continued)

DCAL can provide acute intake IRFs but not chronic intake IRFs. However, this is not a major problem because a convolution integral can be used to calculate chronic intake IRFs from values of the acute intake IRFs.

To illustrate the technique, assume that the fractional retention of the <u>hypothetical</u> radioactive material⁶ in the whole body (the intake retention function or IRF) after an acute instantaneous uptake to the bloodstream is described by the following equation:

$$m(t) = \exp\left(-\frac{\ln(2)}{10\,\mathrm{d}}t\right) \tag{B-1}$$

A plot of the whole-body retention after a unit uptake is shown in Figure B-1, where q(t) is the content of the whole body at *t* days after the uptake.



Figure B-1. Plot of whole-body retention versus time after an acute uptake of the hypothetical radioactive material.

⁶ A biological half-life of 11.25 days is combined with a radiological half-life of 90 days to produce the effective half-life of 10 days used here.

Document No. ORAUT-OTIB-0076	Revision No. 00	Effective Date: 07/10/2014	Page 69 of 73
------------------------------	-----------------	----------------------------	---------------

ATTACHMENT B OBTAINING CHRONIC INTAKE IRFs FROM ACUTE INTAKE IRFs (continued)

The IRF is typically used to calculate an acute intake *I* from the measured whole-body content (i.e., the bioassay result). For example, if the whole-body content is measured to be 100 Bq at 25 days after the acute intake, the intake is estimated to be:

$$I = \frac{q(25 d)}{m(25 d)} = \frac{100 Bq}{\exp\left(-\frac{\ln(2)}{10 d} 25 d\right)} = 566 Bq$$
(B-2)

To do the same sort of calculation for a constant chronic intake, given only the acute intake IRFs and the measured whole-body content, assume the following variables and constants, which are used to construct the plot of the predicted whole-body retention versus time:

- T = length of chronic intake period = 15 days
- t = time that q(t) is measured relative to start of chronic intake = 25 days
- τ = variable time in days
- d_{τ} = infinitesimally short time increment in days
- i = the unit intake rate = 1 Bq/d
- I = IT = the total intake = 15 Bq

The convolution integral⁷ for the curve in Figure B-2 is:

$$q(t) = \int_{\tau=0}^{\tau=T} \left[i d_{\tau} \right] \left[m(t-\tau) \right]$$
(B-3)

Note that id_{τ} is an infinitesimally small intake at time τ and that $m(t - \tau)$ is the acute retention function for that intake. Summing up all the infinitesimally small intakes from time 0 days to time T days gives the content of the whole body at t days resulting from the chronic intake.

To solve the integral, first change variables:

$$\begin{aligned} x &= t - \tau \\ t &= x + \tau \\ dx &= -d, \end{aligned} \tag{B-4}$$

Then express the lower and upper limits in terms of the new variables:

$$\begin{aligned} \tau &= 0 = t - x \\ x &= t \end{aligned} \qquad \text{lower limit} \tag{B-5}$$

$$r = T = t - x$$

 $x = t - T$ upper limit (B-6)

⁷ Note that the IRF must include radiological removal (i.e., the stable element IRF cannot be used here).







This gives the following integral:

$$q(t) = \int_{x=t}^{x=t-T} \left[-idx \right] \left[m(x) \right]$$
(B-7)

Pulling the constant intake rate outside of the integral and reversing the limits puts the integral in a form more suitable for solving:

$$q(t) = \dot{I} \int_{x=t-T}^{x=t} m(x) dx$$
(B-8)

This can in turn be rearranged to give:

$$I = \frac{q(t)}{\frac{1}{T} \int_{x=t-T}^{x=t} m(x) dx}$$
(B-9)

ATTACHMENT B OBTAINING CHRONIC INTAKE IRFs FROM ACUTE INTAKE IRFs (continued)

or:

$$I = \frac{q(t)}{\tilde{m}(t,T)}$$
(B-10)

where:

$$\tilde{m}(t,T) = \frac{1}{T} \int_{x=t-T}^{x=t} m(x) dx$$
(B-11)

is the chronic intake retention function. For the simple example given here the integral can be solved analytically:

$$\tilde{m}(10\,d,25\,d) = \left(\frac{1}{15\,d}\right)_{10\,d}^{25\,d} \exp\left(-\frac{\ln(2)}{10\,d}\,x\right) dx = 0.3108667 \tag{B-12}$$

Once again assuming q(25 d) = 100 Bq:

$$I = \frac{q(t)}{\tilde{m}(t,T)} = \frac{100 \,\text{Bq}}{0.3108667} = 322 \,\text{Bq}$$
(B-13)

DCAL generates tables of acute IRFs for a range of times. These tabulated values are used to create an interpolation function that gives the value of the IRF for any given time. The interpolation function is then numerically integrated to yield a chronic intake IRF as described above. These calculations were performed with a script written in the R programming language.

Document No. ORAUT-OTIB-0076 Rev	evision No. 00	Effective Date: 07/10/2014	Page 72 of 73
----------------------------------	----------------	----------------------------	---------------

ATTACHMENT C

SUMMARY OF GUIDANCE FOR ASSESSING THORIUM INTAKES FROM BIOASSAY

Triple-separated thorium is assumed in the guidance given below. This is applied as a favorable to claimant assumption in the absence of more specific information. If the details of processing are known at a site, these should be used. These methods are approximations and result in intakes that will not underestimate the intakes that would be calculated with exact methods. Approximate methods are not available for ²²⁸Ac chest counts, so such cases must be evaluated with exact methods. Contact the Principal Internal Dosimetrist when a best estimate or evaluation of an ²²⁸Ac chest count is needed.

Chronic Intakes

Given a single ²¹²Pb chest count result for a chronic intake longer than 1 year:

- 1. Evaluate the chest burden using the ²²⁸Th biokinetic model in IMBA.
- 2. Multiply the intake rate obtained in step 1 by a factor of 1.1 and assign it as the intake rate of ²²⁸Th.
- 3. Divide the 228 Th intake rate by 0.19 to obtain the 232 Th intake rate.

Given a single ²¹²Pb whole body count result for a chronic intake longer than 1 year:

- 1. Evaluate the whole-body burden using the ²²⁸Th biokinetic model in IMBA.
- 2. Multiply the intake rate obtained in step 1 by a factor of
 - a. 1.5 for an intake of Type M material
 - b. 1.2 for an intake of Type S material
- 3. Assign the result from step 2 as the intake rate of ²²⁸Th.
- 4. Divide the ²²⁸Th intake rate by 0.19 to obtain the ²³²Th intake rate.

Given a single total thorium urine bioassay result:

- 1. Evaluate the urine result using the ²³²Th biokinetic model in IMBA to obtain the ²³²Th intake rate.
- 2. Multiply the 232 Th intake rate by 0.19 to obtain the 228 Th intake rate.

Given a single ²²⁸Th urine bioassay result:

- 1. Evaluate the urine result using the ²²⁸Th biokinetic model in IMBA to obtain the ²²⁸Th intake rate.
- 2. Divide the ²²⁸Th intake rate by 0.19 to obtain the ²³²Th intake rate.

Acute Intakes

Given a single ²¹²Pb chest count result more than 30 days after an acute intake:

- 1. Evaluate the chest count using the ²²⁸Th biokinetic model in IMBA.
- 2. Multiply the intake obtained in step 1 by a factor of 1.1 and assign it as the intake of ²²⁸Th.
- 3. Divide the ²²⁸Th intake by 0.19 to obtain the ²³²Th intake.
| Document No. ORAUT-OTIB-0076 | Revision No. 00 | Effective Date: 07/10/2014 | Page 73 of 73 |
|------------------------------|-----------------|----------------------------|---------------|
| | | | |

ATTACHMENT C

SUMMARY OF GUIDANCE FOR ASSESSING THORIUM INTAKES FROM BIOASSAY (continued)

Given a single ²¹²Pb whole body count result more than 30 days after an acute intake:

- 1. Evaluate the whole-body burden using the ²²⁸Th biokinetic model in IMBA.
- 2. Multiply the intake in step 1 by a factor of
 - a. 1.5 for an intake of Type M material
 - b. 1.2 for an intake of Type S material
- 3. Assign the result from step 2 as the intake of ²²⁸Th.
- 4. Divide the ²²⁸Th intake by 0.19 to obtain the ²³²Th intake rate.

Given a single total thorium urine bioassay result:

- 1. Evaluate the urine result using the ²³²Th biokinetic model in IMBA to obtain the ²³²Th intake.
- 2. Multiply the 232 Th intake by 0.19 to obtain the 228 Th intake.

Given a single ²²⁸Th urine bioassay result:

- 1. Evaluate the urine result using the ²²⁸Th biokinetic model in IMBA to obtain the ²²⁸Th intake.
- 2. Divide the ²²⁸Th intake by 0.19 to obtain the ²³²Th intake.